

Section J6

Workshop tools

RH 7861	Pre-loading jig — Belleville washers — Final drive right-hand side housing
RH 8014	Torque wrench — 0 lbf.ft. to 600 lbf.ft. Hub yoke nut
RH 8016	Extractor Beam When used in conjunction with RH 8017, RH 8020, RH 8021 and RH 8022, the extractor beam can be used to remove the rear tapered roller bearing from the final drive pinion
RH 8017	Hydraulic Ram To be used in conjunction with RH 8016, RH 8020, RH 8021 and RH 8022 as detailed above
RH 8020	Separator See RH 8017 for uses
RH 8022	Pressure Pads See RH 8017 for uses
RH 8026	Socket head 1. $\frac{1}{16}$ A/F. To be used in conjunction with RH 8014
RH 8032	Stiffening bar — Final drive casing
RH 8307	Converter — Torque Spanner Converts the 19 mm (0.75 in.) square drive of the torque spanner RH 8014 to 25,4 mm (1.0 in.) square drive
RH 8308	Applicator — Rear drive shaft rubber seal
RH 8457	Assembly Tool — Pinion coupling flange
RH 8470	Extractor — Pinion coupling flange To be used in conjunction with RH 8017
RH 9004	Extractor — Rear hub end yoke To be used in conjunction with RH 9005
RH 9005	Hydraulic Ram To be used in conjunction with RH 9004