








Figure D2-9

Turbocharging system – fault diagnosis chart

Sheet 3 of 5

Boost control solenoid valve





isfactorily






Figure D2-9



Turbocharging system – fault diagnosis chart

Sheet 4 of 5

Wastegate



Dump valve



Wiring diagram

- | | |
|----------------------------------|--|
| 1 Knock sensor – A bank | 9 To fuel injection system ECU |
| 2 Knock sensor – B bank | 10 Purge control solenoid (if fitted) |
| 3 From braking system | 11 Fuse |
| 4 From speed control system | 12 Purge control vacuum switch (if fitted) |
| 5 From fuel injection system ECU | 13 Air pressure transducer |
| 6 From ignition system ECU | 14 Boost control solenoid |
| 7 To ignition system ECU | 15 Boost control system ECU |
| 8 To fuel injection system ECU | |





Figure D2-9

Turbocharging system – fault diagnosis chart

Sheet 5 of 5

Brake lamps, Cruise control, and Knock sensors








Figure D3-9


Turbocharging system – fault diagnosis chart

Sheet 1 of 5

Preliminary checks and conditions

Important

1. Unless a fault is absolutely obvious it is recommended that the complete fault finding procedure is carried out
2. Ensure that the battery is fully charged
3. Always use a digital multimeter to carry out electrical circuit tests
4. Always switch off the ignition when either disconnecting or connecting electrical connections
5. Always remake any connection(s) before proceeding to the next test



Visually inspect the electrical connections to the components illustrated below. Detach the multiplug from the boost control ECU and check the integrity of the 15 connections in the plug

Are these satisfactory?

NO

1. Remake the connections
2. Replace the cables

YES

Switch on the ignition
Wait for approximately 10 seconds
Does the boost control valve 'click' continuously?

Note The valve may 'click' briefly for between 5 and 10 seconds when the ignition is switched on

NO

Disconnect the electrical plug from the boost control valve
Switch on the ignition and measure the voltage at the loom connector
Is it 10 to 13 volts?

NO

Check the cables to the boost control solenoid valve

YES

YES

Carry out checks to the air pressure transducer loom

Check the voltage on the purple/brown cable
Is it 4.9 to 5.3 volts?

NO

Check the boost control valve

YES

Check for cable continuity between the black cable and earth
Is it continuous?

YES


Check the air pressure transducer

NO


Rectify faulty cable




Boost control solenoid valve



Air pressure transducer (APT)



Knock sensors



Boost control ECU




Figure D3-9

Turbocharging system – fault diagnosis chart

Sheet 2 of 5

Boost control system air pressure transducer (APT)



Injection system ECU









Figure D3-9

Turbocharging system – fault diagnosis chart

Sheet 3 of 5

Boost control solenoid valve











Figure D3-9

Turbocharging system – fault diagnosis chart Sheet 4 of 5

Wastegate





Dump valve



- | | | |
|--|---|---|
| 1 'A' bank knock sensor | 8 Boost control solenoid | 14 Dump valve vacuum switch |
| 2 'B' bank knock sensor | 9 Right-hand valve 7 way plug and socket | 15 Air pressure transducer |
| 3 Braking system | 10 Dump valve solenoid 2 way plug and socket | 16 EGR ECU |
| 4 Left-hand valve 12 way plug and socket | 11 Dump valve solenoid | 17 EGR ECU |
| 5 Left-hand valve single connection | 12 Left-hand valve 12 way plug and socket | 18 Boost control valve |
| 6 Speed control system | 13 Dump valve vacuum switch 4 way plug and socket | 19 K-Motronic ECU |
| 7 Boost control solenoid 2 way plug and socket | | 20 Parameter code required on catalytic converter |


valve



vacuum switch
transducer

ECU

socket (link
is fitted with
terminals)



- 1 Knock sensor
- 2 Wastegate
- 3 Warm-up catalytic converter
- 4 Intercooler
- 5 Dump valve
- 6 Air pressure transducer
- 7 Dump valve solenoid
- 8 Dump valve vacuum switch
- 9 Air intake filter housing
- 10 Boost control solenoid
- 11 Boost control ECU
- 12 K-Motronic
- 13 Braking system
- 14 Speed control system





Figure D3-9

Turbocharging system – fault diagnosis chart

Sheet 5 of 5

Brake lamps, Cruise control, and Knock sensors





the CO measuring pipe from the main exhaust pipe below the turbocharger.

14. Unscrew the two setscrews securing the oil drain pipe to the bottom of the turbocharger. Free the joint.

15. Unscrew the exhaust clamp ring, securing the turbocharger assembly to the exhaust downtake pipe.

16. Unscrew the four nuts retaining the turbocharger assembly to the exhaust manifold mounting flange. Collect the distance washers.

17. Carefully withdraw the turbocharger assembly, taking care not to damage the machined mating faces of both the turbocharger and the exhaust manifold.

18. Fit the turbocharger by reversing the removal procedure, noting the following.

19. Ensure that the face joint surfaces between the turbocharger and exhaust manifold are clean and undamaged.

20. Torque tighten the retaining nuts to the figures given in Chapter L.

21. Before connecting the lubrication pipes, the turbocharger must be primed with clean engine oil in the following manner.

a. Slowly pour the engine oil into the feed port on top of the turbocharger and manually spin the compressor blades. Exercise care to ensure that the blades are not damaged.

b. Once the oil drains from the port on the bottom of the turbocharger, clean the joint face and fit both the gasket and oil return pipe.

c. Fill the turbocharger through the feed port and then clean the joint face and fit both the gasket and oil feed pipe.

Exhaust wastegate – To remove and fit (see fig. D3-11)

1. Locate the boost pressure pipe connection on the side of the wastegate assembly. Unscrew the male pipe nut and withdraw the pressure pipe.

2. Unscrew the setscrews securing the wastegate to the exhaust manifold. Collect the washers.

3. Withdraw the wastegate and collect the 'O' ring.

4. Fit the wastegate by reversing the removal procedure, noting that the sealing ring fitted between the wastegate and housing must be in good condition.

For the remainder of the information relating to the exhaust system refer to Workshop Manual TSD 4700, Chapter Q.

Air dump valve (recirculation) pipe – To remove and fit

The recirculation pipe is an integral part of the cast intake assembly.

1. Unscrew the worm drive clip securing.
a. the main intake hose to the cast intake assembly.
b. the hose from the air dump valve to the metal pipe.

Twist each hose to free the joint.

2. Unscrew the intake assembly retaining nut and collect the washer (see fig. D3-12).

3. Withdraw the pipe assembly.




Fig. D3-10 Turbocharger and inlet pipes




Fig. D3-11 Exhaust gas wastegate





Fig. D3-12 Air dump valve pipe



A1523

Fig. D3-13 Turbocharger and exhaust fittings

4. Fit the pipe assembly by reversing the procedure, ensuring that the hoses are in good condition.

Air dump valve – To remove and fit

1. Free the two flexible hoses from their respective connections on the bottom of the dump valve (see fig. D3-14).
2. Remove the cast engine air intake elbow (refer to Chapter B, Section B4, Mixture control unit assembly – To remove and fit).
3. Invert the cast elbow.
4. Unscrew the three setscrews retaining the dump valve. Collect the washer fitted under the head of each setscrew.
5. Withdraw the dump valve assembly.
6. Fit the dump valve by reversing the procedure, ensuring that the gasket is in good condition.

Air dump valve – To dismantle, inspect, and assemble (see fig. D3-5)

1. Remove the dump valve from the cast air intake elbow.
2. Collect the rubber sealing ring.
3. Unscrew the two Allen screws retaining the circular end plate to the assembly. Collect the gasket.
4. Unscrew the two through setscrews from the base of the dump valve. Collect the washer from each setscrew.
5. Withdraw the valve from the casting.
6. Unscrew the four setscrews situated around the diaphragm retaining ring.
7. Unscrew the nut from the centre through bolt. Collect the washer.
8. Lift off the seal assembly, diaphragm, spring guide, spring, and base washer.
9. Withdraw the through bolt, guide, and washer from the valve housing.
10. Clean the parts and examine the rubber diaphragm, body sealing ring, and the valve seal assembly plate.
11. Assemble the components by reversing the dismantling procedure.

Air dump valve vacuum switch and solenoid – To remove and test (see fig. D3-5)

This solenoid and switch are fitted adjacent to the air flow sensor potentiometer on the mixture control unit.

Vacuum switch – To remove and fit

1. Disconnect the vacuum signal hose from the switch.
2. Disconnect the electrical connections to the switch, at the 4-way connection.
3. Carefully prise the shakeproof securing washer from the cylindrical body of the switch, below the mounting bracket.
4. Lift the switch from the mounting bracket.
5. Fit the switch by reversing the dismantling procedure.

Vacuum switch – To test

1. Locate the switch electrical connection block and




Fig. D3-14 Dump valve signal hoses

connect a digital multi-meter between the brown cable and earth.

2. Slacken the vacuum switch signal hose clamp screw and withdraw the hose. Connect the Mityvac pump RH 12495 to the connection on the switch.
3. Switch on the ignition noting that the reading on the multi-meter is between 8 volts and 15 volts.
4. Operate the vacuum pump and apply a vacuum to the switch. The meter should read zero when the reading on the gauge is between 317,50 mm Hg and 381,0 mm Hg (12.50 in Hg and 15 in Hg).
5. Slowly release the vacuum, noting that the meter again reads between 8 volts and 15 volts before the vacuum drops below 317,50 mm Hg (12.50 in Hg).
6. If the operation of the switch is suspect, it should be renewed.

Solenoid valve – To remove and fit

1. Disconnect the inlet and outlet hoses from the solenoid valve.
2. Disconnect the electrical connections to the solenoid valve at the 2-way connection block.
3. Carefully slide the solenoid from its rubber mounting.
4. Fit the solenoid valve by reversing the dismantling procedure.

Solenoid valve – To test

1. Disconnect the electrical connections to the solenoid valve at the 2-way connection block. This block is situated between the air potentiometer (mixture control unit) and the solenoid valve.
Note The connection block is usually clipped together with the connection block for the vacuum switch.
2. Slacken the hose clamp screws on the solenoid inlet and outlet connections. Twist each hose to free the joint. Withdraw the two hoses.
3. Connect a suitable length of hose to the front connection on the solenoid and blow down the open end of the hose. It should be possible to blow through the solenoid valve.
4. Connect a 12 volt supply to the solenoid. Note that it should not be possible to blow down the hose



when the solenoid is energized.

Note If the solenoid valve is fitted to the car for this test, exercise care to eliminate the possibility of an electrical spark.

Boost control ECU – To remove and fit
(see fig. D3-6)

1. Disconnect the battery.
2. Remove the front left-hand flasher and side lamp assembly (refer to Workshop Manual TSD 4848).
3. Disconnect the multi-pin plug from the ECU.

Note Do not finger the ECU terminal pins.

4. Unscrew the setscrews securing the engine cooling system expansion bottle to the wing valance. Carefully manoeuvre the expansion bottle into the engine compartment to gain access to the ECU securing screws.
5. Unscrew the three self-tapping screws that retain the ECU to the wing valance.
Support the ECU before the last securing screw is removed.
6. Withdraw the ECU through the front flasher and side lamp wing aperture.
7. Collect the three screw clips from the ECU.
8. Fit the ECU by reversing the removal procedure.

Air pressure transducer (APT) – To remove and fit

1. Disconnect the electrical plug at the APT.
2. Unscrew the metal pipe nut from the adapter on the APT.
3. Unscrew the two mounting screws and withdraw the APT.
4. Fit the assembly by reversing the removal procedure.

Engine knock sensors – To remove and fit

1. Locate the sensor mounted half-way along the crankcase on each side.
2. Detach the electrical plug from the end of the sensor.
3. Unscrew the sensor from the crankcase.
4. Fit the sensors by reversing the removal procedure. Ensure that the heat resistant sleeves fitted to protect each sensor cable, are in good condition and satisfactorily clipped along their entire length.