











Figure F3-4

## Exhaust gas recirculation system – fault diagnosis chart






**Diodes to test**

**Temperature switch circuit diode (see item F and 5)**

- 1 Disconnect the temperature switch plug (see item B and 2)
- 2 Fully open the throttles
- 3 Measure the voltage on the slate/blue cable in the plug. This should be zero

**Throttle position switch circuit diode (see item G and 6)**

- 1 Disconnect the temperature switch plug (see item B and 2)
- 2 Bridge the cables in the plug
- 3 Measure the voltage on the yellow/purple cable in the throttle position switch plug and socket 4 way. This should be zero



**Key**

- 1 Fuse
  - 2 Temperature switch plug and socket (12 way)
  - 3 Temperature switch plug
  - 4 Temperature switch
  - 5 Diode - temperature switch circuit
  - 6 Diode - throttle position switch circuit
  - 7 Solenoid valve plug and socket (2 way)
  - 8 Solenoid valve
  - 9 Engine earth point
  - 10 Throttle position switch plug and socket (4 way)
  - 11 Throttle position switch plug
  - 12 Throttle position switch
- Splice

**Important**

Before carrying out a test ensure that the following conditions apply

1. The battery is fully charged
2. The engine is fully warmed-up
3. Use a multimeter to carry out the electrical circuit tests
4. The engine is switched off when either disconnecting or connecting electrical connections
5. Always remake any connection immediately a test is complete
6. Ensure that fuse B3 on fuseboard 1 is intact
7. Ensure that the test is carried out in a well ventilated area (preferably outside) and without any exhaust extraction or restriction



## Air injection system

The air injection system (see fig. F4-1) consists of a belt driven air pump that delivers air via an air switching valve to the exhaust ports, during engine warm-up. This air combines with the exhaust from the combustion chambers, to promote oxidation of the gases and faster warm-up of the catalytic converter.

When the coolant temperature is above 33°C (91°F) the air switching valve vents the output of the air pump into the engine air intake.

For details of the servicing and maintenance requirements of the air injection system refer to the Service Schedules Manual TSD 4702.

### Air injection pump

The rotary vane pump is mounted at the front of the engine; and belt driven from the refrigeration compressor pulley. Air is drawn into the pump, through a centrifugal filter and exits from a connection on the rear of the pump.

### Air switching valve (see fig. F4-2)

The air switching valve comprises a vacuum operated valve with integral control solenoid.

When the coolant temperature is below 33°C (91°F) the solenoid is energized thus applying inlet manifold vacuum to the diaphragm chamber. This causes the injected air to be re-routed to the exhaust manifolds.

When the solenoid is de-energized (at a coolant temperature above 33°C (91°F)) the manifold vacuum signal is inhibited and the diaphragm chamber vented to atmosphere. This causes the internal spring to return the valve to the rest position, routing the injection air to the engine air intake system.

### Pressure relief valve

A pressure relief valve is fitted between the air injection pump and the air switching valve. It consists of a spring loaded disc that opens at a set pressure. This prevents excessive pressure build-up, that could damage the pump vanes under extreme conditions.

### Check valves

A check valve is fitted into the air injection pipe to each exhaust manifold.

Each valve assembly consists of a spring and one-way disc. The assembly prevents the flow of exhaust gases back to the air switching valve if either the exhaust back pressure exceeds the pump delivery pressure, or the pump belt fails.

### Air pump drive belt

Before commencing to adjust the drive belt inspect it for signs of wear or cracking. If the belt is found unsatisfactory it should be renewed.




Fig. F4-1 Air injection system

- 1 Air pump
- 2 Vent hose to air cleaner
- 3 'A' bank check valve
- 4 Relief valve
- 5 'A' bank exhaust manifold connection
- 6 'B' bank exhaust manifold connection
- 7 Vacuum hose
- 8 Air switching valve
- 9 'B' bank check valve




Fig. F4-2 Air switching valve

- 1 Inlet
- 2 Outlet to engine air intake
- 3 Outlets to exhaust ports
- 4 Inlet manifold vacuum
- 5 Solenoid valve
- 6 Diaphragm chamber
- 7 Atmospheric air bleed
- A Solenoid de-energized
- B Solenoid energized



The belt tension must be checked at a point midway between two pulleys (see fig. F4-3) by use of a belt tension meter.

**Belt dressing must not be applied to prevent belt slip.**

#### Refrigeration compressor to air pump

Load may be applied on either side of the belt run.

#### New belt and retensioning load

Belt tension meter 24,9 kgf to 29,4 kgf  
(55 lbf to 65 lbf)

1. The tension of the belt is adjusted by altering the position of the air pump.
2. Slacken the pivot setscrews located at the front of the air pump. Also slacken the tensioner nut on the threaded adjustment arm.
3. Adjust the tensioner nut until the belt tension is correct.
4. Tighten both pivot setscrews.
5. Check that the belt tension is still correct when the air pump is fully secured.

#### Air pump – To remove and fit

1. Slacken the worm drive clip securing the hose to the pump outlet.
2. Release the belt tension (see Air pump drive belt).
3. Unscrew and remove the pivot setscrews (see fig. F4-3).
4. Fit the air pump by reversing the removal procedure, ensuring that the belt tension is correctly set.

#### Checking the air injection system for leaks and correct operation

To check that the system is functioning correctly, refer to the flow chart (see fig. F4-4).

If an air leak is suspected, proceed as follows.

1. Disconnect the vent hose to the air cleaner (see item A on the flow chart).
2. Start and run the engine.
3. Listen carefully for any evidence of an air leak




Fig. F4-3 Air pump drive belt adjustment and tension check point



from the system. When the coolant temperature increases to approximately 33°C (91°F) the air will be switched from the exhaust manifolds towards the air cleaner. This change can be detected by the noise the air will make as it leaves the open connection of the air switching valve.

4. If an air leak is suspected coat the suspect component with a soap solution; soap bubbles will confirm an air leak.
5. Fit the disconnected hose to the air cleaner.




Figure F4-4

## Air injection system – fault diagnosis chart



**Key**

- 1 Fuse
- 2 Temperature switch plug and socket (12 way)
- 3 Temperature switch plug
- 4 Temperature switch
- 5 Air switching valve link loom plug and socket (2 way)
- 6 Air switching valve plug
- 7 Air switching valve
- 8 Engine earth point
- Splice



thermostat loom plug and socket (item E and 2) continuity on the slate/blue cable

YES → Check the continuity of the slate/blue cable at the thermostat loom plug (see item D and 5)

NO → Check the voltage on the white cable at the plug and socket 12 way Is it 12 volts?

YES → Refer to TSD 4701 Check the ignition feed white cable to fuse B3 on fuseboard 1

NO → Detach the plug from the front temperature switch in the thermostat housing (see item C and 3). Bridge the cables in the plug. Again, check the voltage on the slate/blue cable at the 12 way plug and socket Is it 12 volts?

YES → Replace the temperature switch

NO → Leave the plug to the temperature switch bridged. Disconnect the 12 way plug and socket for continuity of the slate/blue cable and the white cable through the temperature switch plug



Check the continuity of the slate/blue cable at the thermostat loom plug (see item D and 5)

YES → Renew the air switching valve

NO → Check the continuity of the air switching valve link loom for continuity (see item D and 5)

**Important**  
 Before carrying out a test ensure that the following condition apply

- 1 The battery is fully charged
- 2 The engine is cold
- 3 Use a multimeter to carry out the tests
- 4 The ignition is switched off when either disconnecting or connecting electrical connections
- 5 Always remake any connection immediately a test is complete
- 6 Ensure that the fuse B3 on fuseboard 1 is intact





## Three-way catalyst system

The exhaust system is basically of dual pipe construction that utilizes a single catalytic converter in place of a conventional front silencer.

The dual exhaust pipes from the engine combine into a single pipe just prior to the catalytic converter. From the converter, the system reverts to a twin pipe system with both pipes entering a common rear silencer. A single tailpipe then conveys the exhaust to atmosphere.

### Catalytic converter protection

To protect the catalytic converter from possible damage the following precautions should be taken.

### Unleaded gasoline

Use unleaded gasoline only 87AKI (91 RON)\* Min. The use of leaded gasoline will result in a substantial reduction in the performance of the catalyst.

Under no circumstances add fuel system cleaning agents to the fuel tank for induction into the engine, as these materials may have a detrimental effect on the catalytic converter.

\*AKI = Anti-knock index

RON= Research octane number

### Engine malfunction

If the engine misfires or suffers from a lack of power that could be attributed to a malfunction in either the ignition system or fuel system, operation of the vehicle should be discontinued. Driving the vehicle with a malfunction could cause overheating and consequent damage to the catalytic converter.

### Fuel

Do not allow the vehicle to run out of fuel. A warning lamp situated on the fascia illuminates to warn the driver of a low fuel level in the fuel tank. If the vehicle runs out of fuel at high speed, possible damage to the catalytic converter could result.

### Starting the engine


The vehicle must not be pushed or towed to start the engine. Failure to observe this warning could cause overheating and consequent damage to the catalytic converter.

### Exhaust emission control system

It is important that the vehicle is maintained in its correct operating condition. Failure to do so will result not only in loss of fuel economy and emission control but could also cause damage to the catalytic converter due to overheating.


**Catalytic converter – To remove and fit** (see fig. F5-2)

1. Remove the screws retaining the grass-fire shield(s)



**Fig. F5-1 Catalytic converter**

- 1 Stainless steel mesh retaining rings
- 2 Stainless steel mesh
- 3 Monolithic catalyst (1 of 3 blocks)



**Fig. F5-2 Catalytic converter in position**

- 1 Oxygen sensor
- 2 Exhaust joint clamps

located below the catalytic converter.

**Note** Take care when removing the shield(s) as any sharp edges could cause injury to the operator's hands.

2. Ensure that the weight of the catalytic converter is temporarily supported.
3. Support the weight of the downtake pipes.
4. Unscrew and remove the oxygen sensor.
5. Unscrew the nuts from the exhaust clamps forward and rearward of the catalytic converter. Collect the washers and bolts, then free the clamps.
6. Discard the temporary support and withdraw the catalytic converter.
7. Collect the sealing rings from the joints as the converter is removed.
8. Fit the catalytic converter by reversing the removal procedure, noting the following points.
9. The sealing rings and pipe flares must be



thoroughly clean and free from scale. They may be lightly dressed with fine emery cloth if required.

10. Apply Never-seez anti-seize compound to the clamp bolt threads before assembly.

11. The sealing rings, pipe flares, and grooves in the spherical joint clamp brackets should be lightly smeared with either graphite lubricant or Never-seez compound. This will assist alignment of the parts upon assembly.

12. The parts should be loosely assembled and then manoeuvred to give the best alignment, before the joints are tightened.

13. Smear the threads of the oxygen sensor with Never-seez assembly compound. It is important that the Never-seez is applied only to the threads of the unit. Care must be taken to ensure that the compound does not contact the slotted shield below the threaded portion.

Torque tighten the oxygen sensor to the figures given in Chapter L.

**Do not allow the assembly compound to enter the exhaust system, particularly up stream (in front) of the catalytic converter, otherwise damage to the converter assembly will result.**

#### Oxygen sensor warning lamp

On cars conforming to Australian and North American specifications an oxygen sensor warning lamp is situated on the fascia.

When permanently illuminated, the lamp informs the driver that a malfunction has occurred in the 'closed loop' mixture control system. The cause of the malfunction must then be investigated by referring to the appropriate fault diagnosis chart contained in Chapter B.

The warning lamp may illuminate when the engine is being cranked but should extinguish soon after the engine starts. **The lamp will however, remain illuminated until the oxygen sensor reaches its normal operating temperature.**

#### Oxygen sensor

For details relating to the oxygen sensor refer to Chapter B.

#### Exhaust system overheat warning lamp

On cars conforming to a Japanese specification an exhaust overheat warning system is fitted. The warning panel for this system is situated on the fascia. Illumination of the panel indicates that an overheating condition caused through an engine malfunction has been reached in the exhaust system.

If an exhaust overheat condition is indicated, stop the vehicle as soon as possible and switch off the ignition. After three minutes the engine may be started again and providing the overheat warning lamp remains extinguished, the vehicle can be accelerated gently up to a speed of 30 km/h (18 mile/h). This speed must not be exceeded until the cause of the overheat warning has been corrected by referring to the appropriate fault diagnosis flow chart (see fig. F5-3).

To check that the warning panel bulb is operating satisfactorily, ensure that the panel illuminates during engine cranking (i.e. starter motor engaged).

#### Exhaust system

For information relating to the remainder of the exhaust system refer to TSD 4700 Chapter Q, Exhaust system.



Figure F5-3

# Exhaust overheat warning system – fault diagnosis chart

## Sheet 1 of 2

Before carrying out a full diagnostic inspection ensure that the vehicle did not run out of fuel.

If the overheat warning lamp illuminates for reasons other than the above, a fault has occurred in



a. The various systems that lead into the exhaust (fuel system, air intake, etc.) or in the exhaust itself particularly the catalytic converter.

Any faults in these areas can be determined as **system faults**

b. The overheat warning circuit (faulty converter thermocouple, electronic control unit, wiring connections, etc.) causing the lamp to illuminate although the system is operating satisfactorily.

These faults can be determined as **circuit faults**.

- Important**  
Before carrying out the following:
1. The engine must be at normal operating temperature.
  2. The engine must be running.
  3. Use a test light to check the electrical circuit.
  4. The engine must be at normal operating temperature.
  5. Always disconnect the battery before carrying out any electrical work.
  6. Always carry out a full diagnostic inspection of the exhaust system before carrying out any work on the engine.



When carrying out a test ensure that the following conditions apply:  
 - Battery is fully charged  
 - Engine is cold  
 - Use a multimeter to carry out the electrical circuit tests  
 - Engine is switched off when either disconnecting or connecting electrical components  
 - Do not remake any connection until a test is complete  
 - Exercise extreme care when carrying out investigations around the engine and catalytic converter, as components may be very hot.

**Overheat warning**

If an overheat condition is indicated, stop the vehicle as quickly as possible in a safe and orderly manner.

Switch off the ignition.

After three minutes the engine may be started again and providing the overheat warning lamp remains extinguished, the vehicle may be accelerated gently up to a speed of 30 km/h (18 miles/h).

This speed must not be exceeded until the cause of the overheat warning has been corrected.








Figure F5-3

# Exhaust overheat warning system – fault diagnosis chart

## Sheet 2 of 2



connections correctly

amp test circuit.  
1) **NO** Rectify as necessary


**YES**  
atching of the cables in the items C, D, and 12) **NO** Correct the cable mis-match  
ing correct?

**YES**  
the white cable at the socket (see items C, D, **NO** Check the ignition feed white cable from the fuse for 12 volts supply (see wiring diagram)

**YES**  
ple cable from the ECU 4 (see items C, D, and 12) **NO** Check the white/purple cable for continuity and/or short circuiting to another cable  
bulb (see item F and 2)

**YES**  
4 way plug and socket (12) **NO** Rectify the fault on the black cable  
able to the earth point

**YES**  
ECU and thermocouple in test



Key	
1	Diode board 1
2	Warning lamp
3	Other than Eu and socket
4	Engine running plug and socket
5	Speedometer
6	Fuse
7	Right-hand 'A' point
8	Thermocouple
9	Engine comp and socket
10	Catalyst overh 2 way plug ar
11	Electrical cont
12	Catalyst overh 4 way plug ar

