





Figure G3-5

Purge control system – fault diagnosis chart

(Naturally aspirated engines)

Important
 Before carrying out a test ensure the following conditions apply.

1. The battery is fully charged
2. The engine is cold
3. Use a multimeter to carry out tests
4. The ignition is switched off when disconnecting or connecting connections
5. Always remake any connections immediately a test is complete
6. Ensure that fuse B3 on fuseboard is intact
7. Visually inspect the hoses for leaks



re that the

ut the tests
when either
g electrical

tions
eted
board 1 is


or deterioration

ch and

nd circuit

Key

- 1 Fuse
- 2 Temperature switch plug and socket (12 way)
- 3 Temperature switch plug
- 4 Temperature switch
- 5 Diode
- 6 Solenoid plug and socket (2 way)
- 7 Solenoid valve
- 8 Engine earth point
- 9 Throttle position switch plug and socket (4 way)
- 10 Throttle position switch plug
- 11 Throttle position switch
- Splice



nd socket
for continuity.

YES

Replace the solenoid

NO

Rectify the fault on the black earth cable

ch plug
ite cable in the

YES

Measure the voltage on the slate/blue cable as it enters the diode (see item F and 5)
Is it 12 volts?

NO

Check for continuity of the slate/blue cable from the diode to the temperature switch plug (see item D and 5).
This will include the 12 way connector (see item E and 2)

YES

Measure the voltage on the white/purple cable as it exits from the diode
Is it 12 volts?

NO

Replace the diode

YES

able to fuse B3

YES

Measure the voltage on the white/purple cable at the solenoid plug and socket (see item B and 6)
Is it 12 volts?

NO

Check for continuity of the white/purple cable from the control solenoid plug and socket (see item B and 6) to either
Temperature switch circuit - The diode (see item F and 5)
The throttle switch circuit - The switch plug and socket (see item C and 9)

YES

osed
ue/purple cable
plug and socket

Disconnect the solenoid plug and socket.
Check for continuity on the black cable from this plug to the engine earth point (see item G and 8)
Is it continuous?


NO

Rectify the fault on the black earth cable

YES

Replace the solenoid

witch



A1838

E



A1837


F

A1833


G

A1818





able between / plug and 2 way plug





s between and socket





Figure G3-6

**Purge control system – fault diagnosis chart
(Turbocharged engines)
Sheet 2 of 2**



Important
 Before carrying out a test the following conditions apply:


1. The battery is fully charged
2. The engine is cold
3. Use a multi-meter to check connections
4. The ignition is switched off, disconnecting or connecting connections
5. Always remake any connections immediately a test is completed
6. Visually inspect the system for deterioration
7. Ensure fuse B3 on fu

the thermostat
 and then again
 blue cable in the
 plug and socket

ing switch

NO

Check continuity of the slate and the blue cables between the thermostat/engine 12 way plug and socket, and the thermostat switch plug



factory

Ensure that the
 ged

arry out the tests
 off when either
 ting electrical

nections
 mpleted
 lem hoses for

board 1 is intact

- 1 Fuse 15 amp B3 F1
- 2 Engine/Valance 12 way plug and socket
- 3 Purge cut-off solenoid 2 way plug and socket
- 4 Purge cut-off solenoid valve
- 5 Vacuum switch 4 way plug and socket
- 6 Dump valve vacuum switch
- 7 Thermostat/Engine loom plug and socket 12 way
- 8 Temperature switch plug
- 9 Temperature switch
- 10 Purge duty cycle control valve plug
- 11 Purge duty cycle control valve
- 12 Throttle position switch plug and socket 4 way
- 13 Throttle position switch
- 14 Throttle position switch
- 15 Dump valve plug and socket 2 way
- 16 Dump valve solenoid
- 17 K-Motronic ECU

collects the stored fuel vapours. This mixture then passes along a hose from the purge connection on the canister via a cut-off solenoid and restrictor (naturally aspirated cars) or duty cycle purge control valve (turbocharged cars) into the induction manifold.

Operation of the purge system is controlled by the solenoid valve that cuts out the purge flow until a predetermined coolant temperature is reached. On turbocharged cars the solenoid also cuts out the purge flow under boost operating conditions. On naturally aspirated cars and turbocharged cars (without catalytic converters) the solenoid also cuts out the purge flow at idle.

Emission control canister (see fig. G3-3)

The evaporative emission control canister is mounted under the left-hand front wing.

The canister is a cylindrical container filled with activated carbon granules. The top of the canister incorporates a tube, open to atmosphere to admit purge air, together with fuel tank vent and purge connection pipes.

At the mileage specified in the service schedules, remove the control canister and fit a new assembly.

Emission control canister – To remove and fit

1. Locate the emission control canister by removing the appropriate underwing sheet, as follows.
 - 4 door cars – The canister is located behind the front left-hand wheel. Remove the rear section of the underwing sheet.
 - 2 door cars – The canister is located in front of the front left-hand wheel. Remove the forward section of the underwing sheet.
2. The underwing sheet can be withdrawn once the self-tapping screws, situated around the edge of the sheet have been removed.
3. Detach the hoses arrowed in figure G3-3. Label each hose to facilitate identification.
4. On turbocharged cars, disconnect the electrical plug to the duty cycle purge valve.
5. Disconnect the 2-way electrical plug and socket to the solenoid valve.
6. Note the position of the canister and its connections in relation to the various hoses, brackets, and clamping ring.
7. Unscrew the mounting clamp ring securing screw and carefully manoeuvre the canister from its position.
8. Fit the canister to the vehicle by reversing the procedure given for removal.

Fuel tank vent

The fuel tank is vented to the filler neck via two connections. This allows adequate venting of the tank during filling.

A separate vapour line from the centre of the tank (the rollover tube) almost encircles the tank before passing via the vent line and fuel tank pressure control valve to the evaporative loss control canister.




Fig. G3-7 Canister installation – 2 door cars

- 1 Canister
- 2 Cut-off solenoid
- 3 Pressure control valve – fuel tank vent

The vent line is situated under the floor of the car on the left-hand side as shown in figure G3-1. It includes a restrictor at its highest point and passes around the tank to prevent liquid fuel from entering the vent line during harsh manoeuvres or in the event of vehicle inversion.

In the event of a blockage in the vapour line to the control canister, a combined pressure and vacuum relief valve is incorporated into the fuel filler cap. The valve prevents an excessive pressure build-up in the fuel tank caused by fuel vaporization or vacuum as the fuel is consumed.

The fuel tank pressure control valve regulates the release of fuel vapour from the tank vent line to the canister. The valve only opens to allow vapour to pass when the pressure in the tank exceeds the valve setting.

For all other details of the fuel tank refer to Chapter C, Fuel system.

On naturally aspirated cars the flow rate is controlled by a restrictor but on turbocharged cars it is controlled by a purge control valve. This valve regulates the purge flow rate depending upon the engine operating conditions. It receives a duty cycle signal from the engine management system ECU which is programmed with purge control characteristic data.



Purge flow rate – To check

Naturally aspirated cars

1. Fit the flowmeter RH 8725 into the purge line at the restrictor, leaving the restrictor in the hose from the canister.
2. Start and run the engine until normal operating temperature is attained.
3. Increase the engine speed to 2500 rev/min by opening the throttles.
4. Check the purge flow rate is between 26,0 litres/min and 33,0 litres/min (55 ft³/h and 70 ft³/h), except on 1987/88 model year cars for the Middle East or Taiwan when the purge flow rate should be between 9,4 litres/min and 18,8 litres/min (20ft³/h and 40 ft³/h).

Turbocharged cars

1. Connect the flowmeter RH 8725 into the purge line between the induction manifold and the purge control duty cycle valve.
2. Start and run the engine until normal operating temperature is attained. Stop the engine.
3. To carry out the test start the engine and run at idle speed.
4. Note that the purge control system has three phases of operation, as follows.
Phase 1 – 90 seconds delay before purge after starting the engine.
Phase 2 – 150 seconds active purge.
Phase 3 – 15 seconds interval with no purge to allow the lambda pre-control system (if fitted) to learn previous purge/driving cycles.

Continued engine operation results in alternating Phases of 150 seconds active purge and 105 seconds no purge (phases 1 and 3 = 90 seconds + 15 seconds).

Note Operation 4 does not apply to turbocharged cars fitted with a fuel evaporative emission control system that are produced to a Middle East or Taiwan specification.

5. Increase the engine speed to 2000 ± 50 rev/min by opening the throttles.
6. Check that the purge flow rate is between 53 ft³/h and 106 ft³/h (25 litres/min and 50 litres/min), in the 150 seconds active purge phase (refer to Operation 4).

All cars

If the flow is less than the minimum, check for the following.

1. Leak in hoses/pipes.
2. Blockage in hoses/pipes.
3. Control system malfunction.

If the flow is in excess of the maximum, check for the following.

1. Excessively lean mixture strength.
2. Air leak between the throttle body and the induction manifold.