

## Section E14

**Workshop tools**

Tool Number	Description
RH 2684	Wing cover set
RH 2685	Wing cover liners
RH 7094	Valve spring compressor
RH 7095	Extractor - cylinder liner
RH 7097	Extractor - front pulley driving flange
RH 7110	Spanner - crankshaft serrated nut (small)
RH 7126	Spanner - cylinder head nuts
RH 7131	Spanner - crankshaft serrated nut (large)
RH 7200	Base - valve spring compressor
RH 7207	Extraction and Insertion tool - inlet and exhaust valve guides
RH 7208	Extractor - main bearing caps
RH 7272	Guide block
RH 7498	Extractor attachment - main bearing caps
RH 7825	Reamer - inlet and exhaust valve guides
RH 7827	Tipped reamer - inlet and exhaust valve guides
RH 8141	Extractor - oil pump driven gear
RH 8428	Spanner - hydraulic brake pumps serrated nut
RH 9646	Insertion tool - crankshaft rear seal
RH 9655	Protective sleeve - crankshaft rear seal