

Section L6

Workshop Tools

Tool Number	Description
RH 7098	Extractor - Coolant Pump Impeller
RH 8615	Extractor - Coolant Pump Driving Flange