




FIG. 34. ELECTRICAL WIRING DIAGRAM.
 * EARLIER MODELS—THE PETROL PUMP FUSES ARE FITTED SEPARATELY, INSTEAD OF BEING TAKEN OFF THE MAIN FUSE BOARD.