BENTLEY MK. VI.

SECTION Q.

ELECTRICAL AND IGNITION EQUIPMENT.

Containing:-

GROUP 1. BATTERY AND HIGH AMPERAGE CABLES.

2. BOARD DISTRIBUTION.

3. BOXES JUNCTION.

4. COIL, DISTRIBUTOR AND HIGH TENSION LEADS.

4A. COMPANION INTERIOR.

5. DRIVE STARTER MOTOR.

6. DYNAMO AND REGULATOR.

7. EARTH, ENGINE AND DASHBOARD.

8. HEATER, WINDSCREEN.

8A. HEATER, WINDSCREEN.

9. HORN AND MOUNTING.

10. INSTRUMENTS AND MOUNTING.

11. LAMPS AND MOUNTING.

12. MOTOR, STARTER.

13. PLATE, REAR, NUMBER.

13A. REAR LICENCE PLATE (U.S.A).

13B. REAR LICENCE PLATE (SWITZERLAND).

13C. TAIL SWITCH (AUSTRALIA).

14. RADIO AND FITTINGS.

GROUP	14A	RADIO AND FITTINGS (WHEN SPEAKER IS MOUNTED ON STEERING COLUMN.)
	14B	SPARE PARTS FOR RADIO.
	15	SWITCH BOX.
	16	SWITCHES SEPARATE.
	17	TRAFFICATOR.
	18	WINDSCREEN WIPER (BERKSHIRE)
	18A	WINDSCREEN WIPER (LUCAS)
	19	WIRING, DASHBOARD.
	20	WIRING, LOW TENSION AND FITTINGS.
	21	WIRING, FOR STANDARD BODY.

KEY TO CHASSIS NOTES.

Used on	A.B.C.D.E.F, & G Series.	=	F
Used on	H Series onwards	=	G
Used on	A.B & C Series		
" " B-DA	All Chassis.		
" " B-DZ	1-235.	=	H
Used on B-DZ	237 onwards	=	J
Used on	A.B.C.D.E.F.G.H & J Series.		
" " B-KM	All Chassis.		
" " B-KL	1-155, 179 to end.	=	K
Used on B-KL	157-177		
" " B-LJ	2 onwards.	=	L
Used on B	A.B.C & D Series.		
" " B-EY	All Chassis.		
" " B-EW	1-249, 265-271	=	M
Used on B-EW	251-263, 273 onwards	=	N
Used on	A & B Series	=	O

KEY TO CHASSIS NOTES, Contd.

Used on	C Series		
" " B-DA	All Chassis		
" " B-DZ	1-235	=	P
Used on B-DZ	237 to end		
" " B-EY	All Chassis		
" " B-EW	1-271	=	Q
Used on	A,B & C Series		
" " B-DA	All Chassis		
" " B-DZ	1-191	=	R
Used on	A,B & C Series		
" " B-DA	All Chassis		
" " B-DZ	1-261	=	S
Used on B-DZ	263		
" " B-EY	All Chassis		
" " B-EW	1-249, 265-271	=	T
Used on B-FU	523 onwards	=	U
Used on B-DZ	193-261	=	V
Used on B-DZ	263 to end		
" "	E,F,G,H & J Series		
" " B-KM	2-62	=	W
Used on B-KM	64 onwards	=	X
Used on	A,B & C Series		
" " B-DA	2-250	=	Y
Used on B-DA	252 to end		
" " B-DZ	1-191	=	Z
Used on B-DZ	263 to end		
" " B-EY	All Chassis		
" " B-EW	1-249, 265-271	=	FF
Used on B-EW	251-263, 273 onwards		
" " B-FV	All Chassis		
" " B-FU	1-521	=	GG
Used on B-FU	523 onwards		
" "	G Series	=	HH
Used on	H & J Series		
" "	2-62	=	JJ
Used on B-EW	251-263, 273 onwards		
" " B-FV	All Chassis		
" " B-FU	All Chassis	=	KK

KEY TO CHASSIS NOTES, Contd.

Used on B-GT	1 onwards.	= LL
Used on " " B-DA	A,B & C Series. 2-58.	= MM
Used on B-DA " "	60 to end. 1-191.	= NN
Used on B-HR " " B-HP	All Chassis. 1-179, 199.	= OO
Used on B-HP	181-197, 201 onwards.	= PP
Used on " " B-GT	A,B,C,D,E & F Series. 1-335.	= QQ
Used on B-GT " " " " B-JO " " B-JN	33 to end of GT. H Series. All Chassis. 1-205, 209 to end.	= RR
Used on B-JN " " B-KM	207. 2 onwards.	= SS
Used on " " B-CF	A & B Series. 2-378, 382-384, 406, 408, 424.	= TT
Used on B-CF	380, 386-404, 410-422.	= UU
Used up to B-CF	472.	= VV
Used on B-CF	474 onwards.	= WW
Used on B-EY	124, 128-150, 156-174, 178-202, 210-268, 272-300.	= XX
Used on B-EY	126, 152, 154, 176, 204, 206, 208, 270, 302 onwards.	= YY
Used on B-EY	132-142, 162 onwards.	= ZZ
Used on " " B-DA " " B-DZ	A,B & C Series. 2-500. 1-191.	= GGG
Used on B-DZ " " " " B-NZ " " B-NY	103 onwards to end. E,F,G,H,J,K,L & M Series. All Chassis. 1-159, 187, 189, 213, 257.	= HHH
Used on B-NY	169-185, 191-211, 215-255, 259 onwards.	= JJJ
Used on " " B-CF	A & B Series. 2-240.	= KKK

KEY TO CHASSIS NOTES, Contd.

Used on B-CF	242 Onwards.	=	LLL
Used on B-CF " " B-CD " " " " B-EY	474 Onwards. All Chassis. All D Series. 2-300.	=	MMM
Used on " " B-NZ	A,B,C,D,E,F,G,H,J,K,L & M Series. 2-290.	=	NNN
Used on B-NZ	292 Onwards.	=	OOO
Used on " " B-CF	A & B Series. 2-424.	=	PPP
Used on B-CF	426 Onwards.	=	QQQ
Used on " " B-KM	A,B,C,D,E,F,G & H & J Series. 2-62.	=	RRR
Used on B-KM	64 Onwards.	=	SSS
Used on " " B-NZ " " B-NY	A,B,C,D,E,F,G,H,J,K,L & M Series. 2-302, 316-358, 380-468, 478-482, 488, 492 to end. 1-11, 17-19. 37, 41, 43, 47, 51, 53, 57-93, 97-141, 147-151, 157-163, 167-187, 191, 195, 199-211, 215, 219, 223-253, 259-297, 301-309 - on standard steel cars.	=	TTT
Used on " " B-NZ " " B-NY	A,B,C,D,E,F,G,H,J,K,L & M Series. All Chassis. 1-469, 477, 481-487 on coachbuilt cars.	=	TTT
Used on B-NZ " " B-NY	304-314, 360-378, 470-476, 484, 486, 490. 15, 21-35, 39, 45, 49, 55, 95, 143, 145, 153, 155, 165, 189, 193, 197, 213, 217, 221, 255, 257, 299, 311 onwards.- on standard steel cars.	=	UUU
Used on B-NY	471-475, 479, 489-501 onwards - on coachbuilt cars.	=	UUU
Used on B-DZ " " B-EY " " B-EW	193 to end. All Chassis. 1-249, 253-261, 265-271.	=	VVV
Used on B-EW " " " " B-HR " " B-HP	251-263, 273 onwards. F & G Series. All Chassis. 1-179, 199. The above numbers are approximate.	=	WWW

KEY TO CHASSIS NOTES, Contd.

Used on B-HP	181-197, 201 onwards. The above numbers are approximate.	=	XXX
Used on B-JN " " B-B-KM	207. 2 onwards.	=	YYY
Used on B-HP " " B-JO " " B-JN	181-197, 201 to end of HP. All Chassis. 1-205, 209, to end of JN.	=	ZZZ
Used on B-EY " " B-EW	174-182, 214-222, 234 to end. 1-249, 265-271.	=	FFFF
Used on B-DZ " " B-EY	193 to end. 172, 184-212, 224-232.	=	GGGG

GROUP Q.1. BATTERY AND HIGH AMPERAGE

Comprising

	REF. NO.	PART NO.	QUANTITY GROUP	QUANTITY ASS'LY	NOTES
BATTERY, 12 volt, assembly, consisting of	1	RD.4358	1		
Battery Exide 6 MXP-9R P & R 6 HZP 9S		DB.2063		1	
Nut, battery retaining stud		RD.4357		2	
Stud, battery retaining		RD.4356		2	
BOLT, cable clips	X. 9	K.103/Z	5		
BOLT, .250" dia., battery earth to frame	X.10	K.204/Z	1		
BOLT, .250" dia., Solenoid mounting strip, valance plate (LC)	X.10	K.243/Z	2		
CABLE, battery to earth, assembly, consisting of	2	RD.3593	1		
Cable				1	
Eye, angle frame		D.50650		2	
Sleeve, rubber		RD.3305		2	
Terminal, positive to battery		F.56725		1	
CABLE, battery to Solenoid switch assembly, (RC) consisting of	3	RD.3591	1		
Cable					
Eye, straight, Solenoid switch		RD.3102		1	
Sleeve, rubber		RD.3305		1	
Terminal, negative to battery		F.56724		1	
CABLE, battery to Solenoid switch assembly, (LC) consisting of		RD.5005	1		
Cable					
Eye, straight, Solenoid switch		RD.3102		1	
Sleeve, rubber		RD.3305		1	
Terminal, negative to battery		F.56724		1	
CABLE, switch to starter, assembly, consisting of	4	RD.3592	1		
Cable					
Eye, angle, starter motor end		D.50650		1	
Eye, straight, switch end		RD.3102		1	
Sleeve, rubber		RD.3305		1	
CLIPS, cable	5	RD.3041	5		
COVER, terminal, rubber, large dia.	6	RD.3105	2		
COVER, terminal, rubber, small dia.	7	RD.3106	1		
NUT, .250" dia., Solenoid mounting strip to valance plate (LC)		K.4310/Z	1		
NUT, full, .250" dia., battery earth bolt	X.21	K.4008/Z	1		
NUT, full, .250" dia., battery terminal screw	X.21	K.4008	2		+
NUT, full, 2 BA, cable clips	X.21	K.4006/Z	5		
PIECE, distance	9	RD.3099/Z	2		
SCREW, hexagon head, .250" dia., battery terminal	X.55	KC.209/Z	2		+
SCREW, hexagon head, .250" dia., switch retaining	X.55	KC.902/N	2		F
SCREW, hexagon head, 2 BA, switch retaining	X.54	KC.172/Z	2		G
STRIP, mounting Solenoid, assembly (LC)		RF.5030	1		F
STRIP, mounting Solenoid, assembly (LC)		RF.7190	1		G

GROUP Q.1. (Continued overleaf)

GROUP Q1. BATTERY AND HIGH AMPERAGE CABLES (Continued)

	REF. NO.	PART NO.	QUANTITY GROUP	QUANTITY ASS'LY	NOTES
SLEEVING, cable battery to switch	10	RD.3089	1		
SLEEVING, cable switch to starter	11	RD.5459	1		
SWITCH, Solenoid assembly, with terminal nuts and washers		RD.3009	1		F
SWITCH, Solenoid assembly, with terminal nuts and washers	12	RD.5518	1		G
WASHER, plain, 2 BA, switch to mounting strip	X.85	K.4404/Z	2		G
WASHER, plain, .250" dia., battery earth bolt	X.85	K.4407/Z	1		
WASHER, plain, Solenoid mounting strip to valance plate (LC)		K.4407/Z	2		
WASHER, spring, .250" dia., battery earth bolt	X.87	K.9008/Z	1		
WASHER, spring, .250" dia., switch to mounting strip	X.87	K.9008/Z	2		F
WASHER, spring, cable clip	X.87	K.9006/Z			
WASHER, spring, 2BA, switch to mounting strip	X.87	K.9006/Z	2		G
WASHER, spring, Solenoid mounting strip to valance plate (LC)		K.9008/Z	2		G

NOTE:- + Specify 'electro-lead deposited' when ordering.

GROUP Q2. BOARD DISTRIBUTION

Comprising:-

BASE, assembly, consisting of:	1	RD.3031A	1	
Base		RD.3031		1
Bolt, fuse terminal		DW.434		16
Clip, fuse		RD.3034		14
Plate, connecting main fuse		RD.3035		2
Rivet, .093" dia., fuse clip retaining		KB.1823		14
Washer, plain, fuse clip retaining rivet		RD.3036		14
CLAMP, main fuse	2	DW.538	2	
CLIP, cover retaining	3	RD.3033	1	
COVER	4	RD.3032	1	
FUSE, main, 3 strands of .0124 (30 SWG) tinned copper twisted together (4 ft. total length)	5			
HOLDER, fuse assembly, consisting of	6	RD.3686A	7	
Contact		D.76011		2
Holder		RD.3686		1
Wire fuse (as in main fuse)				
HOLDER, spare wire, assembly, consisting of	7	DW.432A	1	
Holder		DW.432		1
Wire fuse, (as in main fuse)				

GROUP Q2. (Continued overleaf)

GROUP Q2. BOARD DISTRIBUTION (Contd.)

SCHEDULE OF SPARE PARTS	REF. NO.	PART NO.	QUANTITY GROUP ASS'LY	NOTES
NUT, half 3 BA, terminal and terminal bolt retaining.	X.24	K. 4304/Z	32	
PIECE, distance, main fuse.	8	D.74845	2	
PIECE, distance, distribution board base.		RD.5906	1	
SCREW, cheese head, 3 BA, board to dashboard retaining.	X.45	K.1828/Z	3	M
SCREW, cheese head, 3 BA, board to dashboard retaining.		K. 1834/Z	3	N
SCREW, cheese head, 3 BA, main fuse distance piece retaining.	9	D.71723	2	
SCREW, cheese head, 3 BA, main fuse distance piece retaining.	X.45	K. 1807/Z	2	
WASHER, plain, 3 BA, board to dashboard retaining screw.	X.85	K. 4446/Z	3	
WASHER, plain, 3 BA, terminal bolt and main fuse screw.	X.85	K. 4447/Z	34	
WASHER, spring, 3 BA, board to dashboard retaining screw.	X.87	K. 9005/Z	3	
WASHER, spring, 3 BA, terminal bolt main fuse screw and distance piece.	X.87	K. 9005/Z	36	

GROUP Q3. BOXES JUNCTION.

Comprising:

BOX, junction, 4 way, assembly, with cover, cover screw and grub screws.	1	RD.3085	2	
BOX, junction, 4 way assembly, with cover, cover screw and grub screws.		RD.3085	1	J
BOX, junction, 6 way, assembly with cover, cover screw, terminal and grub screw (R.C).	2	RD.3086	3	
BOX, junction, 6 way assembly, with cover, cover screw, terminal and grub screw (L.C).		RD.3086	4	
BOX, junction, 12 way, assembly, consisting of:	3	RD.3306A	1	
Base.		RD.3306	1	
Screw, terminal.		RD.3309	12	
Terminal.		RD.3308	12	
BRACKET, mounting coachbuilder's box on dashboard.	4	RD.3098	1	
COVER, 12 way junction box.		RD.3307	1	
NUT, full, 3 BA, 4 and 6 way junction boxes retaining screws (R.C).	X.21	K. 4005/Z	6	H
NUT, full, 3 BA, 4 and 6 way junction boxes retaining screws (R.C).		K. 4005/Z	8	J

GROUP Q3. (Continued Overleaf).

GROUP Q3. BOXES JUNCTION. (Contd.)

	REF. NO.	PART NO.	QUANTITY GROUP ASS'LY	NOTES
NUT, full, 3 BA, 4 and 6 way junction boxes retaining screws (L.C).		K.4005/Z	10	
NUT, half, 3 BA, tail box retaining screw.	X.24	K.4304/Z	2	
PIECE, distance, coachbuilders junction box on dashboard.	6	RD.3099	2	
SCREW, cheese head, 3 BA, body junction box retaining (R.C).	X.45	K.1810/Z	2	
SCREW, cheese head, 3BA, junction box retaining (R.C)	X.45	K.1807/Z	4	H
SCREW, cheese head, 3BA, junction box retaining (R.C)		K.1807/Z	6	J
SCREW, cheese head, 3BA, junction box retaining (L.C)		K.1807/Z	10	
SCREW, cheese head, 3BA, 12 way junction box cover retaining	X.45	K.1814/Z	3	
SCREW, cheese head, 2BA, coachbuilders junction box bracket, on dashboard retaining.	X.46	K.1928/Z	2	
SCREW, 12 way junction box to dashboard, retaining.	7	RD.3310	3	
WASHER, plain, 3 BA, junction box retaining screw	X.85	K.4446/Z	7	H
WASHER, plain, 3 BA, junction box retaining screw.	X.85	K.4446/Z	6	J
WASHER, spring, 3 BA, junction box and 12 way box cover, retaining screws (R.C)	X.87	K.9005/Z	12	H
WASHER, spring, 3 BA, junction box and 12 way box cover, retaining screw (R.C)		K.9005/Z	14	J
WASHER, spring, 3BA, junction box and 12 way box cover, retaining screw (L.C)		K.9005/Z	16	
WASHER, spring, 2 BA, coachbuilders junction on dashboard, retaining screw.	X.87	K.9006/Z		

GROUP Q4 COIL, DISTRIBUTOR AND HIGH TENSION LEADS.

Comprising:

ADAPTOR, lead to plug (Champion) assembly with bush, clip and screw	1	RE.3482A	6	A
ADAPTOR, lead to plug (Lodge)		RE.5925	6	A
BOLT, bracket to dash		KC.902/Z	2	N
BOLT, coil to bracket		K. 203/Z	4	N
BRACKET, Ignition Coil		RD.4726	1	N
COIL, ignition assembly, including cable cap and 2 BA terminal nuts (1 off on early chassis)	2	RD.3012	2	
CONDENSER, coil assembly, consisting of:	3	RD.4031	1	
Condenser, with cable		RD.3410	1	

GROUP Q4. (Continued Overleaf).

GROUP Q4. COIL, DISTRIBUTOR & HIGH TENSION LEADS. (Contd.)

	REF. NO.	PART NO.	QUANTITY GROUP	QUANTITY ASS'LY	NOTES
CONDUIT, front, assembly, consisting of:	4	RE.5469	1		
Bracket.		RE.4781		1	
Eyelet.		RE. 652		3	
Tube.		RE.5468		1	
CONDUIT, rear, assembly, consisting of:	5	RE.4778	1		
Bracket.		RE.4781		1	
Eyelet.		RE. 652		3	
Tube.		RE. 644		1	
DISTRIBUTOR, assembly, including:	6	RD.5897	1		NNN
Distributor.		RD.5896		1	
Cap, distributor.		RD.7616		1	
Condenser, assembly (includes condenser RD.5881).		R. 4481		1	
Contact fixed, base plate.		RD.4269		1	
Contact, fixed, synchro plate.		RD.4270		1	
Contact, moving with bush, spring and pad.				2	
Cover, distributor.				1	
Nut, knurled.		RD.3703		1	
Rotor.		-		1	
Lubricator.		RE.10606			
Plate, clamping.		RD.7565		1	
Pin, taper, driven sleeve.		K. 4802		1	
Sleeve, driven.		RD.3494		1	
Washer, packing for clamping plate.		RD.3046		1	
DISTRIBUTOR, assembly, as above except:		RD.7783	1		000
Distributor case, and		-		1	
Bracket, condensor.		RD.7773		1	
Condensor.		RD.7774		2	
Nut, condenser to bracket.		K. 4301/Z		4	
Screw, condensor to bracket.		K. 1750/Z		4	
Washer, condensor to bracket.		K. 9003/Z		4	
LEAD, H.T. coil to distributor.	7	RE.3466			
LEAD, H.T. Nos.1, 2 & 5 cylinders (Champion).	8	RE.3462			
LEAD, H.T. Nos. 1, 2 & 5 cylinders (Lodge).		RE.9207			
LEAD, H.T. No.3 cylinder (Champion).	9	RE.3463			
LEAD, H.T. No.3 cylinder (Lodge).		RE.9208			
LEAD, H.T. No.4 cylinder (Champion).	10	RE.3464			
LEAD, H.T. No.4 cylinder (Lodge).		RE.9209			
LEAD, H.T. No.6 cylinder (Champion.).	11	RE.3465			
LEAD, H.T. No.6 cylinder (Lodge).		RE.9210			
NUT, coil to dashboard or coil to bracket.		K. 4310/Z	4		
PIECE, distance, coil to dashboard (2 off on early chassis).	12	RD.4009	4		M
PLATE, driving sleeve, distributor.	13	RD.3492	4		
PLUG, sparking, 14 mm. Lodge "CLN".	14	RE.4912	6		
PLUG, sparking, 14 mm. Champion.		RE.4568	6		
RING, driving plate, distributor retaining.	15	RD.3493	1		
WASHER, FS., coil to bracket.		K. 9008/Z	4		N
WASHER, FS., bracket to dash.		K. 9008/Z	2		N
WASHER, FS., coil to dash (2 off on early chassis).		K. 9008/Z	4		M

GROUP Q4A. COMPANION INTERIOR.

Comprising:

	REF. NO.	PART NO.	QUANTITY GROUP	QUANTITY ASS'LY	NOTES
BRACKET, cigar lighter or		RD.3488	1		
BRACKET, cigar lighter.		RB.3991	1		
BULB, 16v. 3w. MES capped.		RD.4242	2		
COVER, terminal, lamp.		RD.3357	2		
HOLDER, bulb.		RD.3353	2		
LIGHTER, cigar interior companion with:		RD.4835	1		
Knob and element.		RD.6205		1	
Socket.		RD.7612		1	
LIGHTER, cigar, interior Companion.		RD.3479	1		
NUT, 7 BA, lighter to bracket (when RD.3479 lighter is used).	X.21	K. 4001/Z	3		
NUT, lock, 3 BA, lamp mounting.	X.24	K. 4304/Z	4		
SCREW, 7 BA, lighter to bracket (when RD.3479 is used).	X.48A	K. 2555/Z	3		
SCREW, No.2, lighter to bracket.		RB.4763	3		
SCREW, 3 BA, lamp mounting.	X.49	K. 2713/Z	4		
SWITCH, see-saw.		RD.3572	2		
TAB, earthing.		RD.4030			

GROUP Q5. DRIVE STARTER MOTOR.

Comprising:

	REF. NO.	PART NO.	QUANTITY GROUP	QUANTITY ASS'LY	NOTES
BEARING, ball, Fischer.	1	RD.7530	1		A
BEARING, ball, Hoffman.		RD.3958	1		A
BEARING, ball, R & M.		RD.5793	1		A
COVER, clutch.	2	DB. 366	1		
CUP, outer clutch plate retaining.	3	RD.3728	1		
DISC, clutch, Ferodo.	4	RD.3726	7		
DISC, clutch, with spigot.	5	RD.3727	3		
DISC, clutch, without spigot.	6	D.51584	3		
GEAR, pinion, assembly, consisting of:	7	DB.1185A	1		
Bush.		DB.1186		1	
Flange.		D.50883		1	
Gear.		DB.1185		1	
KEY, Woodruff, .500" dia., x .0935 thick stop.	X.18	KC. 500	1		A
NUT, ball bearing, retaining.	8	G. 8753	1		
NUT, operating, splined.	9	DB.2271	1		
PLATE, clutch inner.	10	DB.1676	1		
PLATE, clutch outer.	11	D.51585	1		
RING, locking, cover to shell.	12	D.50911	1		
RING, spring, (circular section), damper spring washer retaining.	13	D.51139	1		
RING, spring, (square section) outer clutch plate retaining.	14	D.72370	1		
SHAFT, threaded.	15	DB.2307	1		

GROUP Q5. (Continued Overleaf).

GROUP Q5. DRIVE STARTER MOTOR (Contd.).

	REF. NO.	PART NO.	QUANTITY GROUP	QUANTITY ASS'LY	NOTES
SHELL, driving.	16	D.54612		1	
SPRING, damper.	17	DB. 81		1	
SPRING, dis-engaging.	18	DB.2098		1	
SPRING, engaging (12 lbs.).	19	D.51566		1	
STOP, operating.	20	DB.1674		1	
WASHER, damper spring retaining.	21	DB.1675		1	
WASHER, fibre, outer plate to cover.	22	D.51589		1	
WASHER, fibre, pinion to shell.	23	D.50908		1	
WASHER, lock, ball bearing retaining nut.	24	D.51590		1	
WASHER, plain, ball bearing retaining.	X.85	K. 4419		1	

GROUP Q6. DYNAMO AND REGULATOR.

Comprising:

DYNAMO 4½ inch, Lucas C.45, PV/3N7/0 .2241/D assembly, including:		RD.3006			TT
Armature (238683).		RD.4377			
Bearing 115 (189307).		RD.4368			
Bearing 117 (189308).		RG.4449			A
Bearing 117 (189308).		RG.7079			A
Bolt, .250" trough fixing (238106).		RD.4379			
Bracket, assembly, less bearing (238190).		RD.4373			
Bracket, less brushes and bearings (238685).		RD.4369			
Brush set, (238240).		RD.4371			
Coil set, (238070).		RD.4378			
Cover, assembly (238232).		RD.4367			
Key (189344).		RD.4376			
Nut, (180620).		RD.4374			
Spring, set, brush (238062).		RD.4370			
Washer, shaft D.E. (185187).		RD.4375			
DYNAMO, 5 inch, Lucas RA.5, assembly, including:	1	RD.3679			UU
Bearing.		RD.6204			
Brush, set (2 off per set).		RD.6158			
Screw, adjuster.		RD.6236			
Spring, set brush.		RD.6244			
PULLEY, with cooling fan.	2	RD.4067			
REGULATOR, 4½ inch, dynamo, Lucas RF.96-2.L4.		RD.3082			TT
37052D assembly.					
Choke, assembly (334932).		RD.4394			
Clip, (334906).		RD.4391			
Condensor, (484264).		RD.4395			
Cover, (334904).		RD.4390			
Regulator, LRT. 9-2 (33075A).		RD.4393			
Resistance, assembly, 63 ohms (337920).		RD.4392			

GROUP Q6. (Continued Overleaf).

GROUP Q6. DYNAMO AND REGULATOR. (Contd.)

	REF. NO.	PART NO.	QUANTITY GROUP ASS'LY	NOTES
REGULATOR, 5 inch, dynamo, Lucas RF.9L5/L10 assembly.	3	RE.10621		UU
SCREW, cheese head, 2 BA, voltage control to dashboard retaining.	X.46	K. 1928/Z		
WASHER, plain, 2 BA, regulator to dashboard retaining screw.	X.85	K. 4404/Z		
WASHER, spring, 2 BA, regulator to dashboard retaining screw.	X.87	K. 9006/Z		

GROUP Q7. EARTH ENGINE AND DASHBOARD.

Comprising:

BOLT, .250" dia., cables to frame retaining.	X.10	K. 241/Z	1	
CABLE, earthing, dashboard.	1	RD. 3604	1	
CABLE, earthing, engine assembly, consisting of:	2	RD. 3594	1	
Cable, 8.250" long, double copper braid (tinned).		D. 54573		1
Eye.		RD. 3532		2
NUT, half, 3 BA, earth terminal to dashboard.	X.24	K. 4304/Z	2	
NUT, half, .250" dia., cables to frame retaining bolt.	X.24	K. 4310/Z	1	
SCREW, cheese head, 3 BA, earth terminal.	X.45	K. 1813/Z	2	
WASHER, plain, 3 BA, earth terminal.	X.85	K. 4446/Z	1	
WASHER, spring, 3 BA, earth terminal.	X.87	K. 9005/Z	1	
WASHER, spring, .250" dia., cables to frame retaining bolt.	X.87	K. 9008/Z	1	

GROUP Q8. HEATER, WINDSCREEN (FITTED UP TO B-191-DZ).

Comprising:

BLOWER, de-misting, assembly, Smith's EXX.11776A and CHS 220/1, including mounting bracket and cables.	1	RD. 3356	1
BREECHING.	2	RD. 3365	1
CLIP, Jubilee, No.2 breeching to blower and silencer to air duct connections.	3	RD. 4994	3
CLIP, spring, air duct.	4	RD. 3424	2
COVER, blanking, air duct, with rubber washer RD.3408.	5	RD. 3372	1

GROUP Q8. (Continued Overleaf).

GROUP Q8. HEATER WINDSCREEN. (FITTTED UP TO B-191-DZ) Contd.

	REF. NO.	PART NO.	QUANTITY GROUP	QUANTITY ASS'LY	NOTES
HEATER, assembly, consisting of:	6	RD.3423/A	1		
Base		RD.3423		1	
Element		RD.3231		1	
Nut, 5 BA.		K.4302/N		4	
Screw, 5 BA, support, retaining.		K.1702		2	
Support.		RD.3422		2	
Terminal, cable		RD.3232		2	
Washer, plain, 5 BA, element		K.4402/N		2	
Washer, spring, 5 BA.		K.9003/N		6	
Screw, 5 BA, terminal		K.1711		2	
HOSE, rubber, breeching to air silencer, 1.250" dia.	7	RD.3366	2		
HOSE, rubber, air silencer to duct 1.500" dia.	8	RD.3426	2		
PIECE, distance, blower mounting	9	RD.3369	3		
PIN. air duct spring clip	10	RD.3245	2		
PLATE, blower mounting	11	RD.3367	1		
SCREW, hex head, .250" dia., blower retaining	X.55	KC.207	3		
SILENCER, air, demister blower	12	RD.3362	2		
WASHER, rubber, heater unit base	13	RD.3408	1		
WASHER, spring, .250" dia., blower mounting screw.	X.87	K.9008	3		

GROUP Q8A. RADIATOR HEATER WINDSCREEN.

Comprising:

BLOWER demister	1	RD.4998	1		VVV
BLOWER demister	2	RD.4980	1		WWW
BLOWER demister	3	RD.5940	1		XXX
BOLT, blower mounting.		KC.207/Z	3		VVV
BOLT, mounting pad to blower		KC.206/Z	3		WWW
BOLT, mounting pad to bracket		KC.209/Z	3		WWW
BRACKET, support blower	4	RD.4725	1		WWW
BUSH, mounting pad, blower long	5	RD.5317	3		WWW
BUSH, mounting pad, blower short	6	RD.5318	3		WWW
CLIP, No.2 A connection to silencer		RD.4907	2		
CLIP, No.2 A blower to breeches pipe	7	RD.4907	1		VVV/WWW
CLIP, No.3 blower motor to connection pipe	8	RE.6739	2		XXX
CLIP, No.3 air intake to dash	9	RE.6739	4		VVV
CLIP, No.2 x connection air pipe	10	RE.8936	4		FFFF/WWW
CLIP, No.2 transfer unit to blower motor	11	RD.4994	1		WWW
CLIP, No.3 radiator duct to transfer duct	9	RE.6739	2		WWW
CLIP, blower motor leads	12	RD.5161	1		XXX
COLLAR, adjustable	13	RD.5316	1		WWW
CONNECTION, rubber breeching to silencer	14	RD.3366	2		
CONNECTION, tube to blower intake	15	RD.4286	1		VVV
CONNECTION, radiator duct to transfer duct	16	RD.4970	1		WWW
CONNECTION, demister blower	17	RD.4730	1		WWW
CONNECTION, blower motor to connection pipe	18	RD.5942	1		XXX
CONNECTION, elbow blower	19	RD.4522	1		VVV
CONNECTION, elbow blower	20	RD.4906	1		WWW

GROUP Q8A (Continued Overleaf).

GROUP Q8A. RADIATOR HEATER WINDSCREEN. (Contd.)

	REF. NO.	PART NO.	QUANTITY GROUP ASS'LY	NOTES
CONNECTION, elbow blower.	21.	RD.5944	1	XXX
CONNECTION, rubber, transfer duct.	22	RD.6071	2	FFFF/WWW
CONNECTION, silencer to duct.	23	RD.3426	2	
DUCT, air demister, assembly including:	24	RD.6063	1	GGGG
Clip.		RE.6783	2	
Nut, strap, square.		CS.30981/Z	1	
Pin, split.		KB.6868	2	
Screw, cheese head strap.		K. 1925/Z	1	
Screw, set, clip air duct support.		KC. 172/Z	2	
Strap assembly.		RD.6104	2	
Strip, felt.		RD.7434	1	
Strip, packing, connecting strap.		RD.6103	2	
Washer, FS, strip.		K. 9006/Z	1	
Washer, FS, air duct support clip.		K. 9006/Z	2	
Washer, Thackeray, strap.		K. 3803/Z	1	
DUCT, air demister assembly, as above except for outlet pipe.		RD.6099	1	FFFF
DUCT, air demister, assembly as above except for outlet pipe.	25	RD.5002	1	WWW
DUCT, air, demister assembly as above except for duct.		RD.5924/A	1	ZZZ
DUCT, air demister, assembly including (dividing plate fitted).	26	RD.5924/B	1	YYY
Seal, felt dividing plate.		RD.5945	1	
DUCT, air assembly, front including:	27	RD.5930	1	YYY
Felt, .062" thick, duct to matrix.		RD.5935	1	
Felt, .125" thick, duct to matrix.		RD.5936	1	
DUCT, transfer, assembly.	28	RD.5315	1	WWW
FLANGE, elbow, demister.	29	RD.5946	1	XXX
GROMMET, tube demister.	30	RD.4287	1	VVV
HOSE, air intake to dash.	31	RD.4698	1	GGGG
NUT, front air duct to top tank.	X.24	K. 4307/Z	2	YYY
NUT, pad to support bracket.	X.24	K. 4310/Z	3	WWW
NUT, pad to blower.	X.24	K. 4310/Z	3	WWW
PAD, mounting demister blower.	32	RD.4729	1	WWW
PIECE, distance, blower motor.	33	RD.3369	3	VVV
PIPE, air, dash to duct.	34	RD.6096	1	FFFF
PIPE, breeches.	35	RD.3365	1	VVV
PIPE, breeches assembly with flange.	36	RD.4575	1	WWW/XXX
PIPE, blower to dash (R.C).	37	RD.5938	1	XXX
PIPE, blower to dash (L.C).		RD.5939	1	XXX
PIPE, connection blower to dash.	38	RD.5941	1	XXX
PLATE, mounting blower.	39	RD.3367	1	VVV
SILENCER.	40	RD.3362	2	VVV
SILENCER.	41	RD.4570	2	WWW/XXX
SCREW, cheese head, connection to dash.	X.40	K. 1910/Z	4	WWW/XXX
SCREW, set support bracket to dash.	X.55	KC. 902/Z	4	WWW

GROUP Q8A. (Continued Overleaf)

GROUP Q8A. RADIATOR HEATER WINDSCREEN. (Contd.)

	REF. NO.	PART NO.	QUANTITY GROUP	QUANTITY ASS'LY	NOTES
SCREW, cheese head adjusting plate to air duct.	X.46	K. 1910/Z	4		WWW
SCREW, set front air duct to top tank.	X.54	KC. 152/Z	2		YYY
SCREW, set dashboard sealing.	X.55	KC. 902/Z	4		XXX
TUBE, hose connection.	42	RD.4285	1		VVV
WASHER, plain, mounting pad to blower.	X.85	K. 4407/Z	3		WWW
WASHER, plain, mounting pad to bracket.	X.85	K. 4407/Z	3		WWW
WASHER, plain, front air duct to top tank.	X.85	K. 4404/Z	4		XXX
WASHER, FS, blower mounting.	X.87	K. 9008/Z	3		VVV
WASHER, FS, mounting pad to blower.	X.87	K. 9008/Z	3		WWW
WASHER, FS, mounting pad to bracket.	X.87	K. 9008/Z	3		WWW
WASHER, FS, support bracket to dash.	X.87	K. 9008/Z	4		WWW
WASHER, FS, connection to dash.	X.87	K. 9007/Z	4		WWW
WASHER, FS, adjusting plate to air duct.	X.87	K. 9006/Z	4		WWW
WASHER, FS, breather piece to dash.	X.87	K. 9006/Z	4		XXX
WASHER, FS, front air duct to top tank.	X.87	K. 9006/Z	2		
WASHER, FS, dashboard sealing.	X.87	K. 9008/Z	4		

GROUP Q9. HORN AND MOUNTING.

Comprising:

BOLT, .312" dia. mounting bracket retaining.	X. 6	K. 304/Z	4		
BOLT, 2 BA horn relay bracket to valance plate.		K. 101/Z	2		L
BRACKET, fixing.	1	RD. 3207	2		
BRACKET, horn mounting.	2	RD.4950	2		
BRACKET, horn relay mounting.		RD.6352	1		L
CONNECTOR, horn cables.	3	RD.3425	4		
COVER, terminal.		RD.3106	3		L
GRILLE, horn, assembly, consisting of:	4	RD.3254A	2		
Grille.		RD.3254		1	
Stud, 2 BA.		RD.6026		4	
HORN, W.T.29 low note, R.H. assembly, including:	5	RD.3206	1		
Block, terminal, c/w fixing parts.		RD.4450			
Contact set c/w fixing parts.		RD.4451			
Cover, rear.		RD.4453			
Flex.		RD.4452			
Grommet.		RD.4455			
Housing, c/w bridge, core resistance, terminal and C.B.		RD.4449			
Support, cover fixing.		RD.4454			
HORN, WT.29, high note, L.H. assembly, as above, except:		RD.4265	1		
Housing.		RD.4456		1	

GROUP Q9. (Continued Overleaf)

GROUP Q9. HORN AND MOUNTING. (Contd.)

	REF. NO.	PART NO.	QUANTITY GROUP ASS'LY	NOTES
NUT, full 2 BA. relay retaining.	X.21	K. 4006/Z	2	K
NUT, half, 2 BA. horn grille, retaining.	X.24	K. 4307/Z	8	
NUT, half, .312" dia. horn mounting.	X.24	K. 4313/Z	4	
NUT, half, 2 BA. horn relay bracket to valance plate.		K. 4307/Z	2	
NUT, half, .312" dia. horn mounting.	X.24	K. 4313/Z	4	
RELAY, Lucas, 12v.	6	RD. 3084	1	K
RELAY, Lucas, 12v.		RD.6351	1	L
SCREW, cheese head, 2 BA. horn relay retaining.	X.45	K. 1949/Z	2	K
SCREW, hex. head, .312" dia. horn mounting.	X.56	KC. 296/Z	4	
SCREW, cheese head, 2 BA. horn relay to bracket.		K. 1901/Z	2	L
WASHER, joint, horn grille.	7	RD.3225	8	
WASHER, plain, .312" dia. horn mounting.	X.85	K. 4410/Z	8	
WASHER, spring, 2 BA. grille and relay.	X.87	K. 9006/Z	10	K
WASHER, spring, 2 BA. grille.	X.87	K. 9006/Z	8	L
WASHER, spring, 2 BA. relay to bracket.	X.87	K. 9006/Z	2	L
WASHER, spring, 2 BA. relay bracket to valance.	X.87	K. 9006/Z	2	L
WASHER, spring, .312" dia. horn mounting.	X.87	K. 9009/Z	8	

GROUP Q10. INSTRUMENTS AND MOUNTING.

Comprising:

BOLT, 2 BA., speedometer drive clip frame.	X. 9	K. 102/Z	1	
BOLT, .250" dia., mounting bracket clock condenser.	X.10	K. 202/Z	1	OO/PP
BLOCK, mounting, speedometer cable clip.		RD.3510	1	M
BLOCK, mounting, speedometer cable clip.	1	RD.5101	2	N
BULB, 12v. 2.4w, 4 in 1 instrument.		RD.4243	1	
BULB, 12v. 2.4w, speedo.	2	RD.4243	3	
CABLE, light to switch, speedo.		RD.4860	2	
CLIP, oil pressure gauge pipe.		RF.3291	2	M
CLIP, oil pressure gauge pipe.		RF.3291	3	N
CLIP, thermometer pipe to dash.	3	RF.3291	2	M
CLIP, thermometer tube to induction pipe.	4	RD.3508	4	
CLIP, speedometer drive (D type).	5	RD.3193	1	M
CLIP, speedometer drive (P type).	6	RD.4782	1	
CLIP, speedometer drive.		RD.3193	2	N
CLOCK, 8-day.	7	RD.3184	1	M/GG/HH
CLOCK, electric.	8	RD.5732	1	OO/PP
CONNECTOR, terminal plug, charging point.	9	D.70396	2	Z/V/W/X
DRIVE, speedometer, (RC) (70.000" long).	10	RD.3289	1	
DRIVE, speedometer, (RC) (66.000" long).		RD.4590	1	
DRIVE, speedometer, (RC) (same as RD.4590 but felt washers fitted in knurled end).		RD.5419	1	
DRIVE, speedometer, (LC).		RD.4746	1	
DRIVE, speedometer (LC) (same as RD.4746 but felt washer fitted in knurled end).		RD.5280	1	

Q10. (Continued Overleaf)

GROUP Q10. INSTRUMENTS AND MOUNTING. (Contd.)

	REF. NO.	PART NO.	QUANTITY GROUP	QUANTITY ASS'LY	NOTES
INSTRUMENT, 4 in 1 assembly, consisting of:		RD.4670	1		RRR
Ammeter (30-0-30).		RD.4673		1	
Gauge, fuel.		RD.3786		1	
Gauge, oil pressure.		RD.3780		1	
Thermometer.		RD.3770		1	
INSTRUMENT, 4 in 1 assembly, as above except:	11	RD.7583	1		SSS
Ammeter.		RD.7584		1	
LIGHT, green, fuel warning, assembly, consisting of:	12	RD.3158A	1		
Bulb, 16v. screw fixing.		RD.4242		1	
Holder, bulb.		RD.3115		1	
Housing, bulb holder.		RD.4181		1	
Plate, window.		RD.3171		1	
Screen, light.		RD.4182		1	
Screw, wood.		RD.4837		2	
Spring.		RD.3117		1	
Washer, holder to mounting plate.		RD.3116		1	
Window, green.		RD.3453		1	
LIGHT, red, ignition warning assembly, as for:		RD.3158B	1		
Light, green, RD.3158A, except:					
Window, red.		RD.3452		1	
LIGHTER, cigar, including distance piece.	13	RD.4157	1		
Bracket, nut and 6" of fabric covered cable, with eye, RD.3956.					
Knob and element.		RD.7613		1	
Socket.		RD.7614		1	
NUT, .250" dia. mounting bracket, condenser, clock.	X.24	K. 4310/Z	1		OO/PP
NUT, half, 2 BA. speedometer drive clip, frame.	X.24	K. 4307/Z	1		
PACKING, rubber speedo. drive clip, frame.	14	RD.4783	1		
PLATE, clock mounting.	15	RD.3198	1		M/GG/HH
PLATE, instrument mounting.		RD.5253	1		TTT
PLATE, instrument mounting (when 3-position heater and demister switches are fitted).	16	RD.6698	1		UUU
PLATE, shield.	17	DB.1832	2		
PLUG, moulded, charging point.	18	RD.4333	1		Z/V/W/X
RHEOSTAT, heater.		RD.3441	1		TTT
SCREW, cheese-head, thermometer tube shield.	X.44	K. 1707/Z	4		
SCREW, cheese-head, 5 BA. clock.	X.44	K. 1704/Z	4		M/GG/HH
SCREW, cheese-head, 5 BA, speedo. drive shield retaining.	X.44	K. 1707/Z	4		
SCREW, cheese-head, 3 BA. speedo. drive clip retaining (with twin coils).	X.45	K. 1822/Z	2		M

GROUP Q10. (Continued Overleaf)

GROUP Q10. INSTRUMENTS AND MOUNTING. (Contd.)

	REF. NO.	PART NO.	QUANTITY GROUP	QUANTITY ASS'LY	NOTES
SCREW, cheese-head, 3 BA. speedo. drive clip retaining (with single coil).	X.45	K. 1825/Z	2		M
SCREW, cheese-head, 3 BA. speedo. drive clip retaining.		K. 1831/Z	4		N
SCREW, cheese-head, 2 BA. instrument mounting.	X.46	K. 1907	6		
SCREW, hex. head, 2 BA. instrument mounting plate, retaining.	X.54	KC. 153/Z	6		
SCREW, cheese-head, 2 BA. switchbox, mounting.	X.46	K. 1910/Z	2		
SCREW, cheese-head, 3 BA. terminal socket, charging point.		K. 1804/Z	2		
SCREW, wood, countersunk head, No.3 clock mounting.		CS.31335/V	3		M/GG/HH
SCREW, wood, countersunk head, No.6 socket charging point.		CS.31604/Z	2		
SHIELD, rubber, speedometer drive.	19	RD.3186	1		
SHIELD, rubber, thermometer tube.		DB.1830	1		
SOCKET, plug, charging point.	20	RD.7056	1		Z/V/W/X
SPEEDOMETER, 11 to 41 axle ratio miles per hour (when no warning light is fitted).		RD.3138	1		
SPEEDOMETER, as above but with red warning light.		RD.4840	1		
SPEEDOMETER, as above but with felt washer transferred to head of drive (export cars).		RD.5416	1		
SPEEDOMETER, as above but with green warning light (home cars).	21	RD.5699	1		
SPEEDOMETER, 11 to 41 axle ratio, kilos. per hour.		RD.3467	1		
SPEEDOMETER, as above but with red warning light.		RD.4846	1		
SPEEDOMETER, as above but with felt washer transferred to head of drive.		RD.5489	1		
SPEEDOMETER, 12 to 41 ratio, kilometers per hour (certain exports to France).		RD.5684	1		
SPEEDOMETER, 11 to 41 ratio, kilos. and miles per hour.		RD.3721/2/3	1		
SPEEDOMETER, as above but with red warning light.		RD.4853	1		
SPEEDOMETER, as above but with felt washer transferred to head of drive.		RD.5483	1		
SWITCH, fuel/oil level.	22	RD.3133	1		
SWITCH, map light.	23	RD.3135	1		
SWITCH, defroster.		RD.4964	1		R
Body.		RD.5273		1	
Knob.		RD.4946		1	
SWITCH, demister.		RD.4962	1		TTT
Body.		RD.5273		1	
Knob.		RD.4944		1	
SWITCH, demister, 3-position.	24	RD.6692	1		UUU
Body.		RD.6696		1	
Knob.		RD.6693		1	

GROUP Q10. (Continued Overleaf)

GROUP Q10. INSTRUMENTS AND MOUNTING. (Contd.)

	REF. NO.	PART NO.	QUANTITY GROUP	QUANTITY ASS'LY	NOTES
SWITCH, instrument.	25	RD.4961	1		
Body.		RD.5273		1	
Knob.		RD.4943		1	
SWITCH, windscreen wiper.	26	RD.4963	1		
Body.		RD.5273		1	
Knob.		RD.4945		1	
SWITCH, fog-lamp.	27	RD.4966	1		V/W/X
Body.		RD.5273		1	
Knob.		RD.5816		1	
SWITCH, underseat heater, 3-position.	28	RD.6694	1		UUU
Body.		RD.6696		1	
Knob.		RD.6695		1	
WASHER, plain, 3 BA. terminal charging socket.		K. 4446/Z	2		Z/V/W/X
WASHER, plain, .250" dia. mounting bracket condenser clock.	X.85	K. 4407/Z	1		OO/PP
WASHER, spring, 5 BA. clock mounting.	X.87	K. 9003/Z	4		M/GG/HH
WASHER, spring, 5 BA. speedo. shield screw.	X.87	K. 9003/Z	4		
WASHER, spring, 5 BA. shield thermometer tube.	X.87	K. 9003/Z	4		
WASHER, spring, 3 BA. speedo. drive clip screw.	X.87	K. 9005/Z	2		M
WASHER, spring, 3 BA. speedo. drive clip screw.	X.87	K. 9005/Z	4		N
WASHER, spring, 2 BA. instrument to mounting plate.	X.87	K. 9006/Z	8		
WASHER, spring, 2 BA. instrument mounting plate.	X.87	K. 9006/Z	6		
WASHER, spring, 3 BA. terminal, socket charging plug.	X.87	K. 9005/Z	2		Z/V/W/X
WASHER, spring, 2 BA. speedo. drive clip frame.	X.87	K. 9006/Z	1		
WASHER, spring, 2 BA. speedo. drive clip dash.	X.87	K. 9005/Z	2		M
WASHER, spring, 2 BA. speedo. drive clip dash.	X.87	K. 9005/Z	4		N
WASHER, spring, .250" dia. mounting bracket condenser clock.	X.87	K. 9008/Z	1		OO/PP
WASHER, leather, oil pressure gauge union.		RD.4345	1		

GROUP Q11. LAMPS AND MOUNTING.

Comprising:

ANCHOR, spring centre lamp.	1	RD.3710	1		
BRACKET, assembly, support fog lamp.		RF.9566	2		⊕
BRACKET, assembly, fog lamp mounting bracket R.H.		RF.9578	1		⊕
BRACKET, assembly, fog lamp mounting bracket L.H.		RF.9579	1		⊕
CASING, stop tail lamp, R.H. complete with studs.	2	RD.3535/A	1		
CASING, stop tail lamp, L.H. complete with studs.		RD.3536/A	1		

GROUP Q11. (Continued Overleaf)

GROUP Q11. LAMPS AND MOUNTING. (Contd.)

	REF. NO.	PART NO.	QUANTITY GROUP	QUANTITY ASS'LY	NOTES
COVER, support, bracket fog lamp.		RD.5178	1		⊕
FLAP, hinged, mounting centre lamp.	3	RD.3256	1		
LAMP, inspection, assembly, consisting of:	4	RD.5454	1		ZZ
Bulb, 12v 6w, SBC.		RD.4518		1	
Cable.		RD.4351		1	
Casing.		RD.4865		1	
Clip, plug.		RD.4531		1	
Connection terminal plug.		D.70396		2	
Insert, casing.		RD.4866		1	
Insert, negative plug.		RD.4332		1	
Insert, positive plug.		RD.4331		1	
Moulding plug.		RD.4333		1	
Screw, cheese-head, 5 BA, clip to lamp.		K. 1702/Z		2	
Sleeve, small cable, lamp.		RD.4868		2	
Sleeve, large cable, lamp.		RD.4869		1	
Unit, lamp.		RD.4327		1	
Washer, FS, 5 BA.		K. 9003/Z		2	
LAMP, centre, assembly, consisting of:	5	RD.5132	1		⊕
Bulb, 12v 48w.	6	RF.4516		1	
Bush, rubber.	7	RD.4745		2	
Cable,		RD.4749		1	
Connector.	8	RD.4744		1	
Extension.	9	RD.5068		1	
Lamp, centre.	10	RD.5141		1	
Nut.	11	RD.4978		2	
Pedestal.	12	RD.5070		1	
Sleeve, terminal connector.		RD.3287		1	
LAMP, centre assembly, consisting of:		RD.5141	1		x
Adaptor, assembly.		RD.4469		1	
Bulb, 12v 48w.		RF.4516		1	
Nut, lamp fixing.		RD.4471		1	
Reflector, assembly.		RD.4470		1	
Rim, assembly.		RD.4467		1	
Spring, reflector fixing.		RD.4468		1	
LAMP, centre, assembly, as above except bulb.		RD.3328	1		+
Bulb, 12v 36w.				1	
LAMP, centre, assembly.	5A	RD.5155	2		⊕
Bulb, 12v 36w SCC.	6A	RD.4165		2	
Bush, rubber connectors.		RD.4745		4	
Cable, lamp to connector.		RD.4749		2	
Connector.		RD.4744		2	
Nut.	11A	RD.6109		2	
Sleeve, terminal.		RD.3287		2	
Washer.		K. 4425/Z		2	

GROUP Q11. (Continued Overleaf)

	REF. NO.	PART NO.	QUANTITY GROUP	QUANTITY ASS'LY	NOTES
GROUP Q.11. LAMPS AND MOUNTING. (Continued)					
LAMP, head, assembly complete with (Home)		RD.3936	2		GGG
Bulb, 12v 48w		RF.4516		2	
LAMP, head, assembly complete with (Home)	13	RD.4544	2		HHH
Bulb, 12v 48/48w DC (L.H. Lamp)		RD.5296		1	
Bulb, 12v 48w (R.H. Lamp)		RF.4516		1	
LAMP, head assembly as above except lamp (Home)		RD.6650	1		JJJ
LAMP, head assembly complete with (All export except U.S.A. and Europe)		RD.3970	2		GGG
Bulb, 12v 36w DC		RD.4162		2	
LAMP, head, assembly, complete with (All export except U.S.A. and Europe)		RD.4544	2		HHH
Bulb, 12v 36w DC		RD.4162		2	
LAMP, head, assembly, as above except lamp (all export except U.S.A. and Europe)		RD.6650	2		JJJ
LAMP, head, assembly, complete with (Export Europe)		RD.4542	2		GGG
Bulb, 12v 36/36w 3 pin cap		RD.5330		2	
LAMP, head, assembly, complete with (Export Europe except France)		RD.4544	2		HHH
Bulb, 12v 36w		RD.5329		2	
LAMP, head, assembly, complete with (Export Europe except France)		RD.6650	2		JJJ
Bulb, 12v 36w		RD.5329		2	
LAMP, head, assembly, complete with (Export France)		RD.5446	2		HHH
Bulb, 12v 36/36 DC 3 pin cap		RD.5330		2	
LAMP, head assembly, as above except lamp		RD.6770	2		JJJ
LAMP, head (U.S.A.)		RD.5062	2		GGG/HHH
LAMP, head (U.S.A.)		RD.7053	2		JJJ
LAMP, luggage boot, assembly consisting of	14	RD.4253	1		V/V
Bracket		RD.3360		1	
Bulb, 16v 3w.		RD.4242		1	
Cable, lamp to earth		RD.4254		1	
Cable lamp to switch		RD.4255		1	
Clip		RD.3359		1	
Cover, bulb		RD.3358		1	
Cover, terminal		RD.3357		1	
Eye, cable to bulb holder and earth		RD.3955		2	
Holder bulb		RD.3353		1	

GROUP Q.11. (Continued overleaf)

GROUP Q11. LAMPS AND MOUNTING. (Contd.)

	REF. NO.	PART NO.	QUANTITY GROUP	QUANTITY ASS'LY	NOTES
LAMP, luggage boot, assembly consisting of (Contd.)					
Nut, half 3 BA.		K. 4304/Z		2	
Screw, cheese-head, 3 BA.		K. 1804/Z		2	
Sleeve, rubber.		RD.3294		1	
Washer, spring, 3 BA.		K. 9005/Z		2	
LAMP, luggage boot, assembly, as above except:		RD.4733	1		W/W
Cable, lamp to switch.		RD.4711		1	
Eye, cable switch (Additional).		RD.3406		1	
LAMP, map, assembly, as RD.4253 except:		RD.3959	1		KKK
Cable, lamp to earth.		RD.3878		1	
Cable, lamp to switch.		RD.3813		1	
Eye, cable earth.		RD.3690		1	
LAMP, map assembly, as RD.4733 except:		RD.4314	1		LLL
Bracket lamp.		RD.4278		1	
Cable, map lamp to switch.		RD.4315		1	
Cable, map lamp to earth.		RD.4316		1	
Eye, cable map lamp.		RD.3955		2	
Eye, cable earth.		RD.3690		1	
Sleeve, rubber cable eye.		RD.7589		1	
LAMP, reverse including (L.C):	15	RD.4716	2		
Bulb, 12v 24w.		RE.10604		2	
LAMP, roof assembly with:		RD.3462A	1		H
Bulb, festoon 12v 6w.		RD.4241		1	
LAMP, roof assembly with:		RD.4613	1		A/J
Bulb, 12v 6w 5 BC.		RF.4518		1	
LAMP, roof assembly as above:	16	RD.4742	1		A/J
LAMP, stop tail assembly, consisting of: (When no bulb indexing pin is fitted).		RD.3704	2		D
Bulb, 12v 24/6w.		RF.4517		2	
Lamp stop tail.		RD.3570		2	
Ring, spring, screw lamp.		RD.3685		2	
Screw, fixing, 2 BA, lamp stop.tail.		RD.3684		2	
LAMP, stop tail assembly as above except: (When no bulb indexing pin is fitted).		RD.3705	2		C
Screw, fixing 2 BA, lamp stop tail.		RD.3683		2	
LAMP, stop tail assembly as RD.3704 except: (When bulb indexing pin is fitted).	17	RD.7066	2		D
Bulb, 12v 18/6w.		RD.6602		2	
Lamp.		RD.7065		2	

GROUP Q11. (Continued Overleaf)

GROUP Q11. LAMPS AND MOUNTING. (Contd.)

	REF. NO.	PART NO.	QUANTITY GROUP	QUANTITY ASS'LY	NOTES
LAMP, stop tail, assembly as above except		RD.7067	2		C
Screw		RD.3684		2	
LAMP, side assembly consisting of:	18	RD.4587	2		
Bulb,		RD.5085		2	
Screw, front motif		RD.6575		2	
MOTIF, wing lamp.	19	RD.4535	2		
MOTIF, head lamp.	20	RD.4534	2		GGG/HHH
MOTIF, head lamp.		RD.7125	2		JJJ
MOUNTING, centre lamp	21	RD.3255	1		
NUT, full, 2 BA, stop tail lamp	X.21	K.4006/Z	4		
NUT, half, 2 BA, luggage boot lamp bracket		CS.5506	2		W/WW
NUT, half, 2 BA, luggage boot lamp cable clip	X.24	K.4307/Z	3		
PAD, rubber stop tail lamp.	22	RD.3568	2		
PIECE, bridge, stop tail lamp	23	RD.3569	2		
PIN, pivot, centre lamp flap	24	RD.3240	1		
PIN, plain, .125" dia., spring anchorage	X.28	KB.4458/Z	1		
PIN, split, .031" dia., centre lamp	X.31	K.4646/Z	1		
RING, sealing, head lamp motif screw, 3 BA		RD.4562	2		
RING, sealing, head lamp motif screw, 5 BA		RD.4563	2		
SCREW, cheese-head, 3 BA, head lamp motif front fixing	X.45	K.1804/Z	2		
SCREW, cheese-head, 5 BA, head lamp motif rear fixing	X.44	K.1704/Z	2		
SCREW, C/sk. head 2 BA, fixing head lamp	X.50	K.2802/Z	16		
SCREW, hex. head, .250" dia., centre lamp mounting front fixing	X.55	KC.902/Z	2		
SCREW, hex. head, .250" dia., centre lamp mounting rear fixing	X.55	KC.201/Z	2		
SCREW, securing, rear wing motif	25	RD.6576	2		
SCREW, wood, No.4, attachment roof lamp		CS.34014/Z	2		J
SCREW, 2 BA, luggage and boot lamp bracket	26	CS.30562/Z	2		
SCREW, 4 BA, reverse lamp (LC)	27	CS.30053/Z	4		
SEAL, head lamp		RD.6700	2		
STRIP, tapping motif wing lamp	28	RD.4536	2		
SPRING, hinged flap, centre lamp	29	RD.3709	1		
WASHER, plain, 2 BA, bracket luggage boot lamp		CS.32044/Z	2		
WASHER, plain, 5 BA, centre lamp hinged flap		K.4401/Z	1		
WASHER, plain, 3 BA, head lamp motif, front fixing		K.4446/Z	2		
WASHER, plain, 5 BA, head lamp motif, rear fixing		K.4401/Z	2		
WASHER, spring, 2 BA, bracket luggage boot lamp		CS.6706/Z	2		
WASHER, spring, .250" dia., centre lamp mounting.	X.87	K.9008/Z	3		
WASHER, spring, 3 BA, head lamp motif front fixing		K.9005/Z	2		
WASHER, spring, 5 BA, head lamp motif rear fixing		K.9003/Z	2		
WASHER, spring, 2 BA, stop-tail light	X.87	K.9006/Z	4		

GROUP Q11. (Continued overleaf)

GROUP Q11. LAMPS AND MOUNTING. (Cont.)

NOTE: ⋇ Used if pedestal is not fitted to centre lamp (Home cars).

⊛ Used if pedestal is fitted to centre lamp (Home cars).

+ Used on export cars.

⊕ Used on later chassis in Australia.

GROUP Q12. MOTOR, STARTER.

Comprising:

BEARING, ball, driven gear R & M.		RD.5794	1	
BEARING, ball, driven gear Fischer.		RD.7529	1	
BEARING, ball, driven gear Hoffmann.	1	RD.3957	1	
DOWEL, idler gear bearing pin support.	2	RD.3161	2	
GEAR, driven, assembly, consisting of:	3	DW. 651A	1	
Bush.		DW. 652		1
+ Gear.		DW. 651		1
Plate.		DW.6653		1
GEAR, driving, armature shaft.	4	DB. 986	1	
GEAR, idler, assembly, consisting of:	5	DB. 987A	2	
Bush.		DB. 713		1
+ Gear.		DB. 987		1
HOUSING, gear.	6	RD.4581	1	
JOINT, gear housing to motor.	7	RD.3131	1	
MOTOR, starter, R.C. assembly, including	8	RD.3127	1	
Armature, Assembly (270931)		RD.4387		1
Bearing, Hoffmann LS5 (189295)		RD.4383		1
Bearing, Hoffmann L17 (189308)		RD.4386		1
Bolt .250" dia., trough fixing (255459)		RD.4389		2
Bracket, assembly, with brush boxes (271048)		RD.4381		1
Bracket, with studs (271047)		RD.4385		1
Brushes, set (271050)		RD.4384		1
Cover, assembly (270426)		RD.4380		1
Fields, set (271149)		RD.4388		1
Springs, set brush (271051)		RD.4382		1
MOTOR, starter L.C. same as above except for position of terminal.		RD.4584	1	
NUT, armature shaft, retaining.	9	RD.3129	1	
NUT, externally threaded, ball bearing, retaining.	10	D.76262	1	
NUT, full, 2 BA, gear housing retaining stud	X.21	K. 4006/N	4	
NUT, full, 2 BA, idler gear bracket, retaining stud	X.21	K. 4006	4	

GROUP Q12 (Continued Overleaf)

GROUP Q12. MOTOR, STARTER. (Contd.)

	REF. NO.	PART NO.	QUANTITY GROUP	QUANTITY ASS'LY	NOTES
PIN, bearing, idler gear.	11	DB. 857	2		
PLUG, lubrication hole.	12	RD.5129	1		
SUPPORT, idler, gear bearing pin.	13	DB. 851	1		
WASHER, adjusting, idler gear, .025 " thick.	14	RD.3579	2		A
WASHER, adjusting, idler gear, .030" thick.		RD.3580	2		A
WASHER, adjusting, idler gear, .035" thick.		RD.3581	2		A
WASHER, adjusting, idler gear, .040" thick.		RD.3582	2		A
WASHER, adjusting, idler gear, .045" thick.		G.50062	2		A
WASHER, adjusting, idler gear, .050" thick.		G.50063	2		A
WASHER, adjusting, idler gear, .055" thick.		G.50064	2		A
WASHER, adjusting, idler gear, .060" thick.		G.50065	2		A
WASHER, adjusting, idler gear, .065" thick.		G.50066	2		A
WASHER, aluminium, .312" dia. gear lubricator.	X.83	KB.1077	1		
WASHER, lock, armature shaft retaining nut.	15	DB. 853	1		
WASHER, spring, 2 BA. gear housing retaining stud.	X.87	K. 9006/N	4		
WIRE, locking, ball bearing retaining nut.	16	RD.3162	1		

N.B. - Lucas Part Numbers in brackets.

GROUP Q13. PLATE, REAR NUMBER.

Comprising:

NUMBER PLATE, rear assembly, (Lucas), complete with:	1	RD.3257	1	
Bead, rubber.		RD.4338		
Bulb, 12v. 24w. SCC, reverse.		RF.4518		2
Bulb, 12v. 3w. illumination.		RD.5085		2
Glass, reverse.		RD.4435		2
Glass, plate.		RD.4441		1
Strip sealing, reverse glass.		RD.5337		2
Strip sealing, plate glass.		RD.5338		2
Washer, plate glass.		RD.4440		1
Washer, reverse light.		RD.4983		2
NUMBER PLATE, rear assembly, (Lucas) as above except:		RD.3930	1	
Glass reverse.		RD.4435		1
Glass reverse (amber).		RD.4436		1
NUMBER PLATE, rear assembly, (Cornercroft) with:		RD.4588	1	
Bulb, 12v. 6w. SCC, reverse.		RF.4518		4
Bulb, 12v. 3w. illumination.		RD.5085		2
Panel, glass.		RD.7524		1
Rim and glass assembly, c/w fixing screw.		RD.7525		2
Screw, fixing box to panel or		RD.7519		4
Screw, fixing box to panel.		RD.7518		6
Washer, cork.		RD.7891		2
Washer, fibre.		RD.7592		6

GROUP Q13. (Continued Overleaf)

GROUP Q13. PLATE, REAR NUMBER. (Contd.)

	REF. NO.	PART NO.	QUANTITY GROUP	QUANTITY ASS'LY	NOTES
NUMBER PLATE, rear assembly, (Cornercroft), with:	2	RD.5677	1		
Bulb, 12v. 24w. SCC.		RD.4166		2	
Bulb, 12v. 3w., illumination.		RD.5085		2	
Button, centre, with screw and washer.		RD.7772		2	
Glass, moulded.		RD.7890		2	
Panel, glass.		RD.7524			
Rim and glass assembly (includes RD.7890 of RD.7772).		RD.7738		2	
Screw, fixing box to panel.		RD.7518		6	
Washer, bezel, inner, aluminium (formerly fibre).		RD.7110		2	
Washer, bezel, outer, cork.		RD.7892		2	
Washer, fibre.		RD.7592		6	
Washer, aluminium, reverse lamp.		RD.7110		2	
SEAL, rear number plate (Lucas).	3	RD.3274	1		
SEAL, rear number plate (Cornercroft).	4	RD.5299	1		

GROUP Q13A. REAR LICENCE PLATE.
(Fitted only on cars for use in U.S.A. and at customer's request).

Comprising:

BOLT, clamping, assembly with nut and stud.	3	RD.4339	1		
BRACKET, adjustable.	4	RD.4334	1		
BRACKET, rear number plate, assembly, consisting of:		RD.4318A	1		
Bracket.		RD.4318		1	
Stud.		KB. 365/Z		3	
BRACKET, rear number plate assembly, consisting of:	5	RD.5247A	1		
Bracket.		RD.5247		1	
Stud.	X.68	KB. 350/Z		3	
BULB, 12v. 6w. (2 off when RD.4318 is fitted).		RD.4997	1		
LAMP, number plate (with RD.4318 bracket).		RD.4336	1		
LAMP, number plate (with RD.5247 bracket).	6	RD.5248	1		
NUT, dome, number plate.	7	RD.4337	1		
NUT, half, .250" dia. bracket retaining.	X.24	K. 4310/Z	3		
NUT, 2 BA. number plate.	X.24	K. 4307/Z	2		
PAD, rubber, bracket.	8	RD.4335	1		
SCREW, cheese-head, 2 BA., lamp (with RD.5247 bracket).	X.46	K. 1910/Z	2		
WASHER, plain, .250" dia., bracket.	X.85	K. 4407/Z	3		
WASHER, plain, .250" dia., number plate.	X.86	K. 8833	1		
WASHER, spring, .250" dia.	X.87	K. 9008/Z	3		
WASHER, spring, .250" dia., number plate.	X.87	K. 9008/Z	1		
WASHER, spring, lamp (with RD.5247 bracket).	X.87	K. 9006/Z	2		

GROUP Q13B REAR LICENCE PLATE (Switzerland).

Comprising:

	REF. NO.	PART NO.	QUANTITY GROUP	QUANTITY ASS'LY	NOTES
BOX, junction, 4-way.	9	RD.3085	1		
BOLT, clamping.	3	RD.4339	1		
BRACKET, adjustable	10	RD.6213	1		
BRACKET, rear number plate assembly	11	RD.6214A	1		
Bracket		RD.6214		1	
Stud		KB.350/Z		3	
BULB, 12v. 6w., MBC, number plate lamp.		RD.4997	2		
CABLE, earth, L.H. stop lamp to number plate		RD.6217	1		
CABLE, supply, junction box, to rear number plate		RD.6216	1		
CABLE, supply, lamps to junction box		RD.6218	1		
CABLE, earth, lamps to junction box		RD.6219	1		
LAMP, number plate	6	RD.5248	2		
NUT, dome, number plate	7	RD.4337	1		
NUT, half, .250" dia., bracket retaining		K.4310/Z	3		
PAD, rubber, bracket	8	RD.4335	1		
PLATE, mounting, four-way junction box	12	RD.6215	1		
SCREW, cheese-head, 2 BA., lamp rear number plate	X.46	K.1910/Z	4		
SCREW, junction box, mounting	X.45	N.1807/Z	2		
WASHER, plain, .250" dia., bracket	X.85	K.4407/Z	3		
WASHER, plain, .250" dia., number plate.	X.86	K.8833/Z	1		
WASHER, FS, .250" dia.	X.87	K.9008/Z	3		
WASHER, FS, junction box mounting	X.87	K.9005/Z	2		
WASHER, GS, lamp fixing	X.87	K.9006/Z	4		

GROUP Q13C. TAIL LIGHT SWITCH. (Australia)

Comprising:

CABLE, tail junction box to tail light switch (supply)		RD.4791	1		
CABLE, tail light switch to tail junction box		RD.4792	1		
CABLE, tail light switch, number plate light		RD.4793	2		
CLIP, sleeve		RD.3434	5		
COVER, switch, assembly		RD.4768	1		
ESCUTCHEON, tail light switch		RD.4766	1		
EXTENSION, push button switch		RD.4785	1		
NUT, switch securing		RD.4784	1		
PLATE, assembly, switch mounting		RD.4772	1		
SCREW, self-tapping, switch cover		CS/31020/Z	6		
SCREW, 2 BA. c/sk, escutcheon		CS/33602/E	2		
SEAT, switch cover		RD.4771	1		
SHIM, switch		RD.4787	1		B
SWITCH, tail light		RD.4795	1		
WASHER, escutcheon		RD.4767	1		
WASHER, sealing, push button		RD.4786	1		
WASHER, switch body		RD.4788	1		

GROUP Q14. RADIO AND FITTINGS.

Comprising:

	REF. NO.	PART NO.	QUANTITY GROUP	QUANTITY ASS'LY	NOTES
AERIAL, roof, assembly, fixed roof type.	1	RD.5218	1		
AERIAL, roof, assembly, sliding roof type.		RD.5217	1		
AERIAL, assembly, scuttle type		RD.6401	1		
BOLT, condenser to fuel pump retaining	X.10	K 202	2		
BOLT, 2BA. earthing strip, speedo. (coach built cars).		K. 103/Z	1		
BOLT, 2BA. earthing strip, body bracket (coach built cars).		K. 102/Z	3		
BRACKET, fuel pump condenser.	2	RD.3407	2		
CABLE, lead in, from aerial.	3	RD.6325	1		
CABLE, receiver to earth with cable eyes RD.3352	4	RD.3699	1		
CLIP, aerial lead in cable, lower	5	RD.3700	2		
CLIP, aerial lead in cable, upper.	6	RE.3529	1		
CONDENSER, electric clock (where fitted).		RD.5714	4		TTT
CONDENSER, electric clock (when 3-position heater and demister switches are fitted).		RD.6697	1		UUU
CONDENSER, dynamo, assembly, with:		RD.3412	1		PPP
Condenser.		RD.3410		1	
Eye, cable		RD.3100		1	
CONDENSER, dynamo, assembly, with:		RD.6080	1		
Condenser.		RD.3410		1	
Eye, Cable.		RD.3345		1	
CONDENSER, fuel pump, assembly, with:	7	RD.3414	2		
Condenser.		RD.3411		2	
Eye, cable.		RD.3533		2	
CONDENSER, horn relay, assembly with:		RD.4701	1		
Condenser.		RD.3410		1	
Eye, cable.		RD.3534		1	
Sleeve, rubber		RD.7589		1	
CONDENSER, ignition coil assembly, with:		RD.5230	1		
Condenser.		RD.3410		1	
Eye, cable.		RD.3533		1	
CONDENSER, windscreen wiper assembly.		RD.3411	1		
NUT, 2BA, clip aerial lead in.		CS.5703/Z	1		
NUT, .250" dia. condenser petrol pump		K.4310/Z	2		
NUT, 2BA. earthing strip to body bracket (coachbuilt cars)		K.4307/Z	1		
PACKING, rubber, radio receiver.	8	RD.3403	2		
PIECE, distance, roof aerial	9	RD.3724	1		
PIECE, distance, radio receiver	10	RD.4580	2		B
RECEIVER, radio (prior to 218CF)		RD.3395	1		
RECEIVER, radio (218CF onwards when metal finisher is fitted).	11	RD.4639	1		

GROUP Q14 (Continued Overleaf)

GROUP Q14. RADIO AND FITTINGS (Contd).

Comprising:

RECEIVER, radio (when wooden finisher is fitted).		RD.4954	1
SCREW, binding head, .250" dia. radio mounting.	12	CS.30204/Z	5
SCREW, 2 BA. clip aerial lead in.	13	CS.30566/Z	1
STRIP, earthing body bracket (coachbuilt cars).		RD.4806	3
STRIP, earthing gearbox side cover and silencer to frame (coachbuilt cars).		RD.4807	2
STRIP, earthing speedo. drive to dashboard (coachbuilt cars).		RD.4808	1
STRIP, earthing dash to frame (coachbuilt cars).		RD.4809	1
STRIP, earthing inter. exhaust pipe bracket to frame (coachbuilt cars).		RD.4811	1
STRIP, earthing, induction manifold to dash (coachbuilt cars).		RD.4812	1
WASHER, plain, earthing strip, body bracket (coachbuilt cars).		K. 4404/Z	3
WASHER, spring, .250" dia. fuel pump condenser and radio mounting.	X.87	K. 9008/Z	7
WASHER, spring, 2 BA, aerial lead in clip upper.	14	CS.6731/Z	1
WASHER, spring, earthing strip, speedo. drive (coachbuilt cars).		K. 9006/Z	1
WASHER, spring, earthing strip, body bracket (coachbuilt cars).		K. 9006/Z	3
WASHER, spring, aerial.		K. 9011/Z	1

SPECIAL PARTS REQUIRED WHEN UNDERSILL AERIAL IS FITTED.

AERIAL, undersill.	RD.3972	1
BOLT, .312" dia. aerial support.	K. 302/N	1
BOLT, .312" dia. earthing mounting bracket.	K. 303/N	1
BRACKET, support, aerial.	RD.4155	1
CABLE, lead in, aerial.	RD.3574	1
CLIP, aerial lead in cable.	RD.3700	1
NUT, earthing mounting bracket.	K. 4313/N	1
NUT, aerial support.	K. 4313/N	1
WASHER, plain, earthing mounting bracket.	K. 4410/N	1
WASHER, spring, earthing mounting bracket.	K. 9009/N	1
WASHER, spring, aerial support.	K. 9009/N	1

SPECIAL PARTS REQUIRED WHEN SINGLE ROD UNDERSILL AERIAL IS FITTED.

AERIAL, undersill.	RD.4578	1
BOLT, .312" dia. bracket.	K. 303/N	2
BRACKET, support single rod aerial.	RD.4579	2
CABLE, lead in, aerial.	RD.6326	1
GROMMET, aerial lead in, dash.	RD.4864	1
NUT, aerial bracket.	K. 4313/N	2
WASHER, spring aerial bracket.	K. 9009/N	2

GROUP Q14A. RADIO AND FITTINGS WHEN SPEAKER IS MOUNTED ON STEERING COLUMN.

	REF. NO.	PART NO.	QUANTITY GROUP ASS'LY	NOTES
AERIAL, roof assembly, (fixed roof type).	1	RD.5217	1	
AERIAL, roof assembly, (sliding roof type).		RD.5218	1	
AERIAL, (scuttle).		RD.6401	1	
BOARD, baffle, loudspeaker (L.C).		RD.7537	1	
BOARD, baffle, loudspeaker (R.C).	2	RD.7536	1	
BOLT, condenser to fuel pump retaining.	X.10	K. 202/Z	2	
BOLT, 2 BA. control unit and centre support bracket to side bracket.	X. 9	K. 101/Z	2	
BOLT, clamping bracket to mounting bracket.	X.10	KC. 202/Z	1	
BOLT, clamping bracket to mounting bracket.	X.10	KC. 205/Z	1	
BOLT, 2 BA. earthing strip, speedo. drive (coachbuilt cars).		K. 103/Z	1	
BOLT, 2 BA. earthing strip to body bracket (coachbuilt cars).		K. 102/Z	3	
BRACKET, assembly, radio mounting, R.H.	3	RD.6620	1	
BRACKET, assembly, radio mounting, L.H.	4	RD.6621	1	
BRACKET, clamping, steering column to bracket.	5	RD.7535	1	
BRACKET, fuel pump condenser.	6	RD.3407	2	
BRACKET, support, control unit, assembly.	7	RD.7609	1	
BRACKET, mounting rear, assembly.	8	RD.7538	1	
BRACKET, baffle to dash, assembly (R.C).	9	RD.7602	1	
BRACKET, baffle to dash, assembly (L.C).		RD.7603	1	
CABLE, control unit to power pack.	10	RD.7042	1	
CABLE, lead in from aerial.	11	RD.6325	1	
CABLE, receiver to earth with cable eyes, RD.3352		RD.3699	1	
CLIP, aerial lead in, cable, lower.	12	RD.3700	2	
CLIP, aerial lead in, cable, upper.	13	RD.3529	1	
CLIP, earthing, speedo. drive (coachbuilt cars).		RD.4805	1	
CONDENSER, electric clock.		RD.5714	1	
CONDENSER, dynamo assembly, with:		RD.6088	1	
Condenser.		RD.4224		1
Cable.		RD.6089		1
Cover, terminal.		RD.3106		1
Eye, cable.		RD.3890		1
CONDENSER, fuel pump, assembly, with:	14	RD.3414	2	
Condenser.		RD.3411		2
Eye, cable.		RD.3533		2
CONDENSER, hose relay, assembly, with:		RD.4701	1	
Condenser.		RD.3410		1
Eye, cable.		RD.3534		1
Sleeve, rubber.		RD.7589		1
CONDENSER, ignition coil, assembly, with:		RD.5230	1	
Condenser.		RD.3410		1
Eye, cable.		RD.3533		1
CONDENSER, windscreen wiper assembly.		RD.3411	1	

GROUP Q14A. (Continued Overleaf)

GROUP Q14A. RADIO AND FITTINGS WHEN SPEAKER IS MOUNTED ON STEERING COLUMN. (Contd.)

	REF. NO.	PART NO.	QUANTITY GROUP ASS'LY	NOTES
CONTROL, unit, radio.	15	RD.7041	1	
GROMMET, rubber support bracket.	16	RF.5032	2	
LOUDSPEAKER, external.	17	RD.7560	1	
NUT, 2 BA. upper lead in cable clip.	18	CS.5703/Z	1	
NUT, 2 BA. earthing strip speedo. drive (coachbuilt).	X.24	K. 4307/Z	1	
NUT, 2 BA. earthing strip to body bracket (coachbuilt).	X.24	K. 4307/Z	3	
NUT, half, .250" dia. fuel pump condenser retaining bolt.	X.24	K. 4310/Z	2	
NUT, 2 BA. control unit and centre support bracket to side bracket.	X.24	K. 4307/Z	2	
PIECE, packing, radio received.	19	RD.4580	2	B
PIECE, distance, roof aerial.	20	RD.3724	1	
PIECE, distance, control unit.	21	RD.7557	2	
PIECE, distance, steering column to bracket.	22	RD.7542	1	
PIECE, distance, bolt, clamping bracket.	23	RD.7543	1	
POWER unit.	24	RD.7559	1	
SCREW, clip, lead in.	25	CS.30566	1	
SCREW, wood, speaker to baffle.	26	CS.31620/Z	4	
SCREW, .250" dia. binding head, radio mounting.	27	CS.30204/Z	5	
SCREW, set, 2 BA. rear, control unit.	X.54	KC. 152/Z	1	
SCREW, set, 2 BA. side bracket to control unit.	X.54	KC. 174/Z	2	
SCREW, set, 2 BA. power amplifier to side bracket (R.H.)	X.54	KC. 152/Z	1	
SCREW, set, 2 BA. power amplifier to side bracket (L.H.)	X.54	KC. 170/Z	1	
SCREW, set, 2 BA. stiffener to power amplifier.	X.54	KC. 151/Z	2	
SCREW, baffle board to bracket.	28	CS.30163/E	3	
STRIP, earthing body brackets (coachbuilt cars).		RD.4806	3	
STRIP, earthing, gearbox side cover and silencer to frame (coachbuilt cars).		RD.4807	2	
STRIP, earthing, speedo. drive to dashboard (coachbuilt cars)		RD.4808	1	
STRIP, earthing, dash to frame (coachbuilt cars).		RD.4809	1	
STRIP, earthing, inter exhaust bracket to frame (coachbuilt cars).		RD.4811	1	
STRIP, earthing, induction manifold to dashboard (coachbuilt cars).		RD.4812	1	
WASHER, FS. side bracket.		K. 9006/Z	2	
WASHER, FS. side bracket to control unit.		K. 9006/Z	2	
WASHER, FS. side rear, control unit.		K. 9006/Z	1	
WASHER, FS. power amplifier unit to side bracket.		K. 9006/Z	4	
WASHER, FS. control unit and centre support bracket to side bracket.		K. 9006/Z	2	
WASHER, FS. bolt, clamping bracket.		K. 9008/Z	2	
WASHER, FS. bolt, speaker to baffle.		K. 9008/Z	4	
WASHER, FS. aerial.		K. 9011/Z	1	
WASHER, FS. clip, lead in.		CS.6731/Z	1	
WASHER, FS. condenser, petrol pump.		K. 9008/Z	2	
WASHER, FS. earthing strip speedo. drive.		K. 9006/Z	1	
WASHER, FS. earthing strip body bracket.		K. 9006/Z	3	
WASHER, FS. radio mounting.		K. 9008/Z	5	
WASHER, plain, 2 BA. rear, control unit.		K. 4416/Z	2	
WASHER, plain, 2 BA. rear control unit (bevelled edge).		KB.3904/Z	1	
WASHER, plain, 2 BA. side bracket to control unit.		K. 4404/Z	2	

GROUP Q14A. (Continued Overleaf)

	REF. NO.	PART NO.	QUANTITY GROUP	QUANTITY ASS'LY	NOTES
GROUP Q14A. RADIO AND FITTINGS WHEN SPEAKER IS MOUNTED ON STEERING COLUMN. (Contd.)					
WASHER, plain, power amplifier to side bracket.		KB.3904/Z		2	
WASHER, plain, earthing strip, body bracket.		K. 4404/Z		3	
GROUP Q14B. SPARES PARTS FOR RADIOMOBILE RECEIVER.					
Comprising:					
LAMP, 12v.		RD.4526		1	
VALVE, W.81M. (113417A).		RD.4477		2	
VALVE, X.81M. (113418A).		RD.4478		1	
VALVE, DL.82. (113419A).		RD.4479		1	
VALVE, KT.81. (113420A).		RD.4480		1	
VALVE, U.82. (113421).		RD.4481		1	
VIBRATOR, 12v. (36212H).		RD.4482		1	
GROUP Q15. SWITCHBOX.					
Comprising:					
ARM, main contact, assembly, consisting of:	1	DW. 222		2	
Arm.		D.74904			1
Bush.		D.74288			1
Connector.		D.74908			1
Shoe.		D.74905			1
Spring.		D.74909			1
Rivet, shoe, retaining.		KB.2356			2
Rivet, spring, retaining.		KB.2406			1
BALL, steel, .3125" dia., main and ignition levers.	2	RG.6954		2	
BARREL, starter contact.	3	D.74946		1	
BASE, switch, assembly, consisting of:	4	RD.3968A		1	
+ Base.		RD.3968			1
+ Bush, ignition spindle.		D.75087			1
+ Bush, main spindle.		D.75088			1
+ Insert, screwed.		D.75085			2
+ Pivot.		D.75086			2
BODY, assembly, consisting of:	5	RD.3055A.		1	
Body.		RD.3055			1
Bush.		E.85851			2
Stud, base and cover, retaining.		D.74955			3
BOLT, 5 BA. starter switch, retaining.	X.7	K.3711/Z		4	
BRUSH, accessories, consisting of 6 stampings D.74925 - and dynamo brush stampings D.74260	6	D.74960		1	
COVER.	7	RD.3056		1	

GROUP Q15. (Continued Overleaf)

GROUP Q15. SWITCHBOX. (Contd.)

	REF. NO.	PART NO.	QUANTITY GROUP ASS'LY	NOTES
CARBON, contact, starter and retaining bush D.74661 (1) a spring D.74667.	8	D.76082	1	
LOCK, Vaughan.		D.75098	1	
NUT, 2 BA. switchbox mounting.		K. 4307/Z	2	
OPERATING, lever, ignition and cam (RD.6037).	9	D.76102	1	
OPERATING, lever main.	10	D.76103	1	
PACKING, brush.	11	D.74324	2	
PACKING, brush, accessories.	12	D.74924	1	
PACKING, brush, battery.	13	D.74928	1	
PACKING, brush ignition.	14	D.74931	4	
PACKING, brush, parking light and starter.	15	D.74296	4	
PIECE, coupling.	16	D.75873	1	
PIECE, distance.	17	D.54862	1	
PIN, split, .031" dia., contact spindle.	X.31	K. 4646/Z	2	
PLATE, angle, accessories.	18	D.74934	1	
PLATE, angle, dynamo arm.	19	D.74957	1	
PLATE, angle, fuel pump.	20	D.74938	1	
PLATE, angle terminals.	21	D.74939	3	
PLATE, angle terminals.	22	D.74940	2	
PLATE, backing, starter, switch, short.	23	D.74949	2	
PLATE, contact, long.	24	D.74950	2	
PLUG, ignition, lever spring, retaining.	25	D.74900	1	
PLUG, main lever spring, retaining.	26	D.74899	1	
PUSH, button, starter and insulating bush, D.74659 (1).	27	RD.3192	1	
RING, starter push.	28	E.51034	1	
SCREW, cheese-head, 7 BA. connection retaining.	X.43	K. 1669/Z	1	
SCREW, cheese-head, 5 BA. accessories brush.	X.44	K. 1722/Z	2	
SCREW, cheese-head, 5 BA. dynamo arm.	X.44	K. 1737/Z	2	
SCREW, cheese-head, 5 BA. finger spring.	X.44	K. 1750/Z	2	
SCREW, cheese-head, 5 BA. fuel pump connection.	X.44	K. 1713/Z	1	
SCREW, cheese-head, 5 BA. ignition supply.	X.44	K. 1707/Z	1	
SCREW, cheese-head, 5 BA. lamps connection.	X.44	K. 1731/Z	2	
SCREW, cheese-head, 5 BA. pass light brush.	X.44	K. 1707/Z	1	
SCREW, cheese-head, 3 BA. terminals.	X.45	K. 1801/Z	8	
SCREW, cheese-head, 2 BA. switchbox mounting.		K. 1910/Z	2	
SCREW, countersunk head, 5 BA. lock.	X.48	K. 2604/Z	5	
SPINDLE, ignition coupling, assembly, consisting of:	30	DW.558	1	
Contact.		D.54864	1	
Coupling.		D.74917	1	
Nut, half, 3 BA.		K. 4304/Z	2	
Piece, distance.		DW. 557	1	
Spindle, operating.		D.74918	1	
Washer, adjusting, .022 thick (24 SWG).		RD.3148	1	A
Washer, adjusting, .028" thick (22 SWG).		RD.3149	1	A
Washer, adjusting, .036" thick (20 SWG).		RD.3150	1	A
Washer, plain, 3 BA.		K. 4446/Z	1	
Washer, spring, 3 BA.		K. 9005/Z	1	

GROUP Q15. (Continued Overleaf).

	REF. NO.	PART NO.	QUANTITY GROUP	QUANTITY ASS'LY	NOTES
GROUP Q.15. SWITCHBOX (Continued)					
SPINDLE, main contact, assembly, consisting of:-	31	RD.3189A	1		
Bush, insulating		D.74903		1	
Bush, insulating, large		D.74898		1	
Contact, front, main		D.74894		1	
Contact, rear, main		D.74896		1	
Coupling		D.74264		1	
Coupling, barrel		D.74897		1	
Nut, coupling, retaining		D.74265		1	
Ring, securing		D.74276		1	
Spindle		D.74895		1	
Washer, insulating, large		D.50341		2	
Washer, large steel, chamfered		D.74275		1	
Washer, plain, thrust, large		RD.3190		1	
Washer, insulating		RD.7546		1	
SPRING, CAMS	32	RD.3191	2		
SPRING, starter button return	33	D.74669	1		
STOP, brush	34	D.74932	1		
STOP, brush	35	D.74933	1		
STOP, brush, parking light	36	D.74295	1		
STOP, brush, to starter and ammeter	37	D.74926	1		
SWITCH, master, contact maker	38	D.74902	1		
TAB, locking, main switch lever	39	D.74266	1		
WASHER, spring carbon contact	40	D.74668	1		
WASHER, insulating, small, main contact spindle	41	D.1426	2		
WASHER, plain, adjacent to spring washer on main contact spindle		K.4404/Z	1		
WASHER, plain, finger spindle and spring		K.4402/Z	4		
WASHER, plain, 3 BA, ignition switch		K.4446/Z	1		
WASHER, plain, studs and terminals		K.4446/Z	11		
WASHER, plain, thrust, small, main contact spindle	42	RD. 3188	1		
WASHER, spring, 7 BA, connection		K.9002/Z	1		
WASHER, spring, 5 BA, brush screw, finger spring, lamp screws, starter switch		K.9003/Z	16		
WASHER, spring, 3 BA, studs and terminals		K.9005/Z	11		
WASHER, spring, 2 BA, main contact spindle		K.9006/Z	1		
WASHER, spring, 2 BA, switchbox screw		K.9006/Z	2		
WASHER, Thackeray, 3 BA cover studs		K.3902/Z	3		
GUARD, switchbox keys		DW. 868	1		
GROUP Q.16. SWITCHES SEPARATE.					
Comprising:					
BASE, stop and reverse light switch assembly, consisting of:-	1	DW.237A	1		
Base		DW. 237		1	
Insert, bracket		D.100456		2	
Insert, terminal		D.73732		2	

GROUP Q.16. (Continued overleaf)

GROUP Q16. SWITCHES SEPARATE. (Contd.)

	REF. NO.	PART NO.	QUANTITY GROUP	QUANTITY ASS'LY	NOTES
CAP, spring, stop and reverse light switch.	2	DW. 235	1		
CAP, rubber, footswitch.	3	RD.5153	1		
CLIP, cover, stop and reverse light switch.	4	DB. 410	1		
CLIP, tail light switch cables.	5	RD.3434	1		x
CONTACT, stop and reverse light switch.	6	DB. 525	2		
COVER, stop and reverse light switch.	7	DB. 408	1		
NUT, roof light switch.	8	RD.4118	2		VV
NUT, half, 3 BA. stop and reverse light contacts and terminals.	X.24	K. 4305/Z	4		
NUT, half, 3 BA. stop and reverse light switch base.	X.24	K. 4304/Z	2		
PIN, split, .062" dia., stop and reverse light spring cap retaining.	X.31	K. 4602/Z	1		
PLATE, contact stop, stop and reverse light switch.	9	DB. 526	2		
PLUNGER, stop and reverse light switch, assembly consisting of:	10	DW. 234A	1		
Rod, operating.		DW. 234		1	
Support, insulation.		DW. 233		1	
Tube, contact.		DB. 414		1	
SCREW, cheese-head, 2 BA, footswitch retaining.	X.46	K. 1910/Z	2		
SCREW, No.2, luggage boot lamp.	11	RD.4778	2		W
SPRING, contact, stop and reverse light switch.	12	DB. 417	1		
SWITCH, foot, Lucas No.FS.22.	13	DB.2360	1		
SWITCH, progressive, on/off luggage boot lamp.	14	RD.4062	1		VV
SWITCH, seesaw, luggage boot lamp.	15	RD.3572	1		WW
SWITCH, progressive, on/off tail light.		RD.4062	1		x
SWITCH, door, roof light.	16	RD.3830	4		XX
SWITCH, roof light manual.	17	RD.3282	2		VV
SWITCH, roof light see saw.		RD.3572	2		WW/XX
SWITCH, starter solonoid, See Group Q1.					
WASHER, plain, stop and reverse light switch terminals.	X.85	K. 4447/Z	2		
WASHER, spring, 3 BA. stop and reverse light switch, base and contacts.	X.87	K. 9005/Z	6		
WASHER, spring, 2 BA. footswitch retaining.	X.87	K. 9006/Z	2		

x Normally fitted to cars for use in Australia.

GROUP Q17. TRAFFICATOR.

Comprising:

HANDLE, trafficator time switch.	1	RD.3466	1	
PIECE, distance, time switch.	2	RD.4560	1	
SCREW, time switch retaining.	3	RD.4350	2	
SCREW, trafficator fixing.	4	RD.3954	2	
SWITCH, time, assembly with handle screw.	5	RD.3107	1	

GROUP Q17. (Continued Overleaf)

GROUP Q17. TRAFFICATOR. (Contd.)

	REF. NO.	PART NO.	QUANTITY GROUP	QUANTITY ASS'LY	NOTES
TRAFFICATOR, Lucas No.SF.34.LH. 54003A assembly including:	6	RD.3211	2		
Arm, assembly.		RD.4444		1	
Bulb, 12v.		RD.4167		1	
Cover.		RD.4445		1	
Eyelet.		RD.4448		1	
Lead.		RD.4446		1	
WASHER, locking trafficator, screw.	7	RD.3953	2		
WASHER, spring, time switch screw.	8	RD.3273	2		

GROUP Q18. WIPER WINDSCREEN (Berkshire).

Comprising:

ARM, wiper, assembly.	1	RD.4139	2	
BLADE, wiper.	2	RD.4138	2	
BOLT, .250" dia. motor mounting.	X.10	K. 209/Z	2	
BUSH, rubber, fixing screw.	3	RD.3520	4	
BUSH, rubber, fixing screw.		RD.3521	4	
CABLE, earthing, with cable eye, KB.5593-4.	4	KB.5568A	1	
COLLET, arm to spindle.	5	RD.4159	2	
DRIVE, flexible, between gear boxes.	6	RD.3777	1	
DRIVE, flexible, motor to gearboxes.	7	RD.3776	1	
GEARBOX, Houdaille, RAD.37 with switch knobs.	8	RD.3775	2	
GROMMET, rubber, drive cables.	9	RD.3436	1	
GROMMET, rubber, wiper spindle.	10	RD.3275	2	
MOTOR, Berkshire, with rubber mounting pad and distance pieces, RD.4041.	11	RD.3774	1	
NUT, collet operating.	12	RD.4245	2	
NUT, half, .250" dia. motor mounting bolt and dashboard, blanking screw.	X.24	K. 4310/Z	2	
PACKING, rubber, gearbox mounting.	13	RD.3687	2	
PIN, split, .062" dia. gearbox retaining.	X.31	K. 4601/Z	4	
SCREW, binding, .250" dia. dashboard, blanking.		CS.30641/Z	1	
STOP, rubber, blade retaining.	14	RD.4246	2	
STUD, gearbox mounting (fitted in windscreen heater duct).	15	RD.3688	4	
WASHER, plain, .250" dia. dashboard blanking.	X.84	KB.3905/Z	2	
WASHER, plain, motor mounting bolt.	X.84	KB.3905/Z	2	
WASHER, plain, wiper gearbox.	X.85	K. 4404	4	
WASHER, rubber, fixing screw.	16	RD.3522	4	
WASHER, spring, .250" dia. motor mounting bolt, and dashboard blanking.	X.87	K. 9008/Z	3	
WIRE, locking stud.		RD.4328	4	

GROUP Q18A. WIPER, WINDSCREEN (Lucas).

Comprising:

ARM, wiper, or		RD.4139	2	

GROUP Q18A. (Continued Overleaf)

GROUP Q18A. WIPER, WINDSCREEN (Lucas), (Contd.)

	REF. NO.	PART NO.	QUANTITY GROUP	QUANTITY ASS'LY	NOTES
ARM, wiper.	1	RD.4816	2		
BLADE, or		RD.4138	2		
BLADE.	2	RD.7562	2		
BLOCK, rubber mounting.	3	RD.6222	3		
COLLET, wiper arm (used with RD.4139 arm).		RD.4244	2		
COLLET, wiper arm (used with RD.4816 arm).	4	RD.4819	2		
GROMMET, wiper spindle.	5	RD.4137	2		
GROMMET, cable.	6	RD.4237	1		
MOTOR, spindle boxes and drive assembly including: (R.C).		RD.4140	1		M
Cable and rack assembly with cross head.	7	RD.6227		1	
Clip, cable.	8	RD.6225		1	
Knob.	9	RD.5351		2	
Wheel box assembly with switch.	10	RD.6229		1	
Wheel box assembly less switch.		RD.6330		1	
MOTOR, spindle boxes and drive assembly (R.C) as above, except for cable assembly. (Used with RD.4139 arm).		RD.5443	1		N
MOTOR, spindle boxes and drive assembly (R.C) as above, except for spindle. (Used with RD.4816 arm).	11	RD.5950	1		N
MOTOR, spindle boxes and drive assembly (L.C) as above, except for re-arrangement of spindle boxes and drive. (Used with RD.4139 arm).		RD.4967	1		
MOTOR, spindle boxes and drive assembly (L.C) as above, except for spindle. (Used with RD.4816 arm).		RD.5641	1		
NUT, collet, wiper arm (used with RD.4139 arm).		RD.4245	2		
NUT, collet, wiper arm (used with RD.4816 arm).	12	RD.4820	2		
NUT, 2 BA. spindle box mounting (when fitted).		R. 4307/Z	4		
PIECE, distance, spindle boxes (when fitted).	13	RD.4143	4		
PLATE, mounting spindle box, R.H. (when fitted).	14	RD.4239	1		
PLATE, mounting spindle box, L.H. (when fitted).		RD.4240	1		
SCREW, cheese-head, 2 BA. spindle boxes mounting (when fitted).	X.46	K. 1907/Z	4		
SCREW, c/sk. head, 2 BA. spindle boxes mounting (when fitted).	X.50	K. 2807/Z	4		
STOP, wiper arm.		RD.4246	2		
WASHER, mounting, spindle boxes.	15	RD.4319	4		B
WASHER, plain, 2 BA. mounting spindle boxes .	X.85	K. 4404/Z	4		
WASHER, FS. 2 BA. mounting spindle boxes.	X.87	K. 9006/Z	4		

GROUP Q19. WIRING DASHBOARD.

Comprising:

CLIP, 18 mm. bore, PVC tubing, L.H. dash.	1	RD.3043	2		M
CLIP, 14 mm. bore, PVC tubing, R.H. dash.		RD.3042	1		M
CLIP, 18 mm. bore PVC tubing.		RD.3043	3		N
CLIP, Jubilee, loom to connection.		RD.4608	1		

GROUP Q19. (Continued Overleaf)

GROUP Q19. WIRING DASHBOARD. (Contd.)

	REF. NO.	PART NO.	QUANTITY GROUP ASS'LY	NOTES
CLIP, support sleeving.		RD.5100	2	N
CLIP, L.H. dashboard conduits.		RD.3058	3	N
CLIP, L.H. dashboard conduit.	2	RD.3058	1	N
CLIP, foot switch conduit.	3	RD.3059	2	M
CLIP, R.H. dash conduit.	4	RD.3060	1	M
CLIP, R.H. dash conduit.		RD.4936	1	N
CONDUIT, L.H. side of dashboard.	5	RD.3062	1	M
CONDUIT, L.H. side of dashboard.		RD.5105	1	N
CONDUIT, R.H. side of dashboard.	6	RD.3063	1	M
CONDUIT, R.H. side of dashboard.		RD.4937	1	N
CONDUIT, horizontal.	7	RD.4014	1	M
CONDUIT, to foot switch.	8	RD.3061	1	M
CONNECTION, switchbox loom to dashboard.	9	RD.3073	1	
ELBOW, conduit, L.H. side of dashboard.	10	RD.3065	1	M
ELBOW, conduit, L.H. side of dashboard.		RD.5103	1	N
ELBOW, conduit, R.H. side of dashboard.	11	RD.3066	1	M
ELBOW, conduit, R.H. side of dashboard.		RD.5102	1	N
GROMMET, rubber.	12	RD.3097	1	M
SCREW, cheese-head, 2 BA. conduit clip retaining.	X.46	K. 1904/Z	5	M
SCREW, cheese-head, 2 BA. conduit clip retaining (9 only on coachbuilt cars.)		K. 1904/Z	10	N
SCREW, cheese-head, 2 BA. conduit clip retaining.	X.46	K. 1907/Z	5	M
SCREW, cheese-head, 2 BA. conduit elbow retaining.	X.46	K. 1922/Z	4	
SCREW, cheese-head, 2 BA. conduit elbow L.H.		K. 1922/Z	2	N
SCREW, cheese-head, 2 BA. conduit elbow R.H.	X.46	K. 1928/Z	2	N
SCREW, cheese-head, 2 BA. connection to dashboard retaining.		K. 1904/Z	2	
WASHER, spring, 2 BA. conduit elbow clip and connection retaining screws.	X.87	K. 9006/Z	16	

GROUP Q20. WIRING, LOW TENSION AND FITTINGS.

Comprising:

BOLT, 2 BA, harness clip (R.C).	X. 9	K. 103/Z	25	O
BOLT, 2 BA, harness clip (R.C).		K. 103/Z	17	P
BOLT, 2 BA, harness clip (R.C).		K. 103/Z	18	Q
BOLT, 2 BA, harness clip (R.C).		K. 103/Z	19	N
BOLT, 2 BA, harness clip (L.C).		K. 103/Z	27	
CABLE, charging plug to connector (Reg 'E').		RD.5755	1	U
CABLE, charging plug to connector (Dist. Board).		RD.5756	1	R
CABLE, defroster switch to defroster unit.		RD.3799	1	R
CABLE, defroster unit to earth.		RD.3861	1	R
CABLE, distribution board '11' to coil.		RD.4012	1	M
CABLE, footswitch to distribution board.		RD.3794	1	R
CABLE, front junction box to horn L.H. & R.H.		RD.6048	2	
CABLE, horn button, L.H. front junction box to horn relay.		RD.5168	1	
CABLE, horn relay supply to horn relay coil.		RD.3810	1	
CABLE, horn relay to L.H. front junction box (horn) (L.C).		RD.5165	1	

GROUP Q20. (Continued Overleaf).

GROUP Q20. WIRING, LOW TENSION AND FITTINGS. (Contd.)

CABLE, ignition coil to distributor.	RD.5683	1		
CABLE, L.H. front junction box to horn relay.	RD.5164	1		
CABLE, 12-way junction box to wiper motor.	RD.3807	1		M
CABLE, 12-way junction box to footswitch supply.	RD.3793	1		M
CABLE, 12-way junction box to solonoid switch 'H'.	RD.3796	1		M
CABLE, regulator 'E' to earth.	RD.3795	1		
CABLE, solonoid switch to earth (R.C).	RD.3617	1		
CABLE, solonoid, switch to main fuse.	RD.3789	1		S
CABLE, solonoid, switch to main fuse.	RD.6007	1		T
CABLE, wiper motor to earth.	RD.3808	1		M
CLIP, cable luggage boot lamp switch.	RD.4257	4		
CLIP, cable luggage boot lamp switch.	RD.6082	3		
CLIP, Trimount spring, L.T. cable to coil retaining.	RD.3434	1		M
CLIP, harness, 11 mm. (R.C).	RD.3041	10		
CLIP, harness, 11 mm. (L.C)	RD.3041	17		
CLIP, harness, 14 mm. horn cable (R.C.).	RD.3042	2		S
CLIP, 11 mm. sleeving reverse light switch (L.C).	RD.4746	3		
CLIP, 14 mm. valance plates and cross members.	RD.3042	7		
CLIP, 7 mm. sleeving heater junction box.	RD.5161	1		Q
CLIP, 7 mm. sleeving heater junction box.	RD.5161	2		N
CLIP, 5 mm. sleeving horn cable.	RD.6082	2		T/N
CLIP, 5 mm. sleeving oil sump unit.	RD.4004	3		T/N
CLIP, cable oil sump unit.	RD.4004	2		S
CLIP, cable electric clock cubby box.door.	RD.6082	1		OO/PP
CLIP, 18 mm. sleeving.	RD.3043	3		
CLIP, 18 mm. sleeving R.H. valance plates.	RD.3043	3		
CLIP, 18 mm. sleeving main trunk.	RD.3043	3		
COVER, terminal car heater.	RD.3106	2		H
GROMMET, rubber (L.C).	RD.3209	7		
LOOM, instrument board, assembly, (R.C), consisting of:	RD.3823	1		R
Cable, demister to heater switch.	RD.3797		1	
Cable, demister switch to defroster switch.	RD.3798		1	
Cable, instrument light switch to map light switch.	RD.3812		1	
Cable, screen wiper switch to fuel gauge.	RD.3816		1	
Cable, fuel gauge, to fuel oil switch.	RD.3817		1	
Cable, heater switch to screen wiper switch.	RD.3862		1	
Cable, switch box '8' to ammeter.	RD.3844		1	
Cable, earth, light, 4 in 1 instruments.	RD.4545		1	
Eye, cable (Dowler).	RD.3690		7	
Eye, cable (Lucas).	RD.3344		1	
Sleeve, rubber.	RD.7589		8	
LOOM, instrument board assembly (R.C) as above but RD.3798 deleted.	RD.5718	1		V
LOOM, instrument board assembly, (R.C) as above except:	RD.5009	1		W
Cable switch box '8' to ammeter (replaces RD.3844).	RD.6016		1	

GROUP Q20. (Continued Overleaf)

GROUP Q20. WIRING LOW TENSION AND FITTINGS. (Contd.)

	REF. NO.	PART NO.	QUANTITY GROUP	QUANTITY ASS'LY	NOTES
LOOM, instrument board (R.C) assembly as above except:	RD.7634		1		
Cable, radio to cigar lighter (additional).	RD.6577			1	
Cable, switchbox '8' ammeter (replaces RD.6016).	RD.7595			1	
Eye, cable 3 BA. (Lucas).	RD.3344			2	
Eye, cable (Dowler) (additional).	RD.3533			1	
Sleeve, rubber.	RD.7589			10	
LOOM, instrument board to dashboard assembly (R.C) consisting of:	RD.3822		1		Y
Cable, distribution board to switch box.	RD.3843			1	
Cable, ammeter to regulator 'A1'.	RD.3845			1	
Cable, switchbox '2' to regulator 'A1'.	RD.3846			1	
Cable, switchbox '8' to distribution board '8'.	RD.3848			1	
Cable, switchbox '11' to distribution board '11'.	RD.3849			1	
Cable, front cigar lighter to distribution board '8'.	RD.3851			1	
Cable, demister switch to distribution board '11'.	RD.3852			1	
Cable, switch box '4' to twelve way junction box.	RD.3853			1	
Cable, switch box '5' to distribution board '5'.	RD.3854			1	
Cable switch box '6' to distribution board '6'.	RD.3855			1	
Cable, instrument board to dash.	RD.3856			1	
Cable, switch box '10' to 12-way junction box.	RD.3858			1	
Cable, trafficator switch to distribution board '6'.	RD.3865			1	
Cable, trafficator switch, L.H. to 12-way junction box.	RD.3870			1	
Cable, trafficator switch R.H. to 12-way junction box.	RD.3871			1	
Cable, wiper switch to 12-way junction box.	RD.3872			1	
Cable, heater switch to 12-way junction box.	RD.3874			1	
Cable, instrument light switch to distribution board '5'.	RD.3877			1	
Cable, fuel oil switch to 12-way junction box (petrol tank unit).	RD.3879			1	
Cable, fuel pipe switch to 12-way junction box (oil sump unit).	RD.3880			1	
Cable, fuel warning light to 12-way junction box.	RD.3882			1	
Cable, ignition warning light to regulator 'D'.	RD.3884			1	
Cable, coachbuilders junction box to distribution board '8'.	RD.3790			1	
Eye, cable 3 BA. (Lucas).	RD.3344			8	
Eye, cable, 3 BA. (Dowler).	RD.3690			16	
Eye, cable, 2 BA. (Dowler).	RD.3533			1	
Eye, cable, cigar lighter.	RD.3956			1	
Sleeving, 30 mm.	RD.3080			1	
Sleeve, rubber, cable eye (R.C).	RD.7589			25	

GROUP Q20. (Continued Overleaf).

GROUP Q20. WIRING LOW TENSION AND FITTINGS. (Contd.)

	REF. NO.	PART NO.	QUANTITY GROUP	QUANTITY ASS'LY	NOTES
LOOM, instrument board to dash, assembly (R.C) as above except:		RD.5388	1		Z
Cable, charging plug to regulator 'E' (additional).		RD.4660		1	
Cable, charging plug to distribution board (additional).		RD.4661		1	
Eye, cable 3 BA, (Lucas).		RD.3344		11	
Sleeve, rubber cable eye.		RD.7589		28	
LOOM, instrument board to dash assembly, (R.C) as above except.		RD.5143	1		
Cable, fog lamp switch to 12-way junction box (additional).		RD.4553		1	
Cable, distribution board to fog lamp switch (additional).		RD.4555		1	
Eye, cable 3 BA. (Dowler).		RD.3690		17	
Sleeve, rubber.		RD.7589		29	
LOOM, instrument board to dash (R.C) as above except:		RD.6027	1		FF
Cable, switchbox (-) to distribution board (-) (replaces RD.3843).		RD.6017		1	
Cable, switchbox (2) to regulator A.1 (replaces RD.3846).		RD.6018		1	
Cable, switchbox (8) to distribution board '8' (replaces RD.3848).		RD.6019		1	
Cable, ammeter to regulator 'A' (replaces RD.3845).		RD.6020		1	
Cable, speedo. to coachbuilders junction box (additional).		RD.4849		1	
LOOM, instrument board to dash (R.C) assembly, as above except:		RD.5812	1		GG
Cable, demister switch to 12-way junction box (additional).		RD.5012		1	
Cable, fog lamp switch to 12-way junction box (replaces RD.4533).		RD.5014		1	
Cable, fog lamp switch to distribution board '5' (replaces RD.4555).		RD.5015		1	
LOOM, instrument board to dash assembly, (R.C) as above except:		RD.6446	1		HH
Cable, regulator 'E' to charging plug connector (additional).		RD.5753		1	
Cable, distribution board to charging plug connector (additional).		RD.5749		1	
Connector, male, charging plug (additional).		RD.5745		2	
Eye, cable 3 BA. (Lucas).		RD.3344		9	
Sleeve, rubber.		RD.7589		27	
Sleeving, 11 mm. charging plug connector (additional).		RD.5761		1	

GROUP Q20. (Continued overleaf).

GROUP Q20. WIRING LOW TENSION AND FITTINGS. (Contd.)

LOOM, instrument board to dash assembly (R.C) (Contd.)

The following are deleted:-
Cable, charging plug to regulator 'E' RD.4660.
Cable, charging plug to distribution board RD.4661.

LOOM, instrument board to dash assembly (R.C) as above, except:	RD.5763	1	JJ
Cable, electric clock (additional).	RD.5721	1	
Cable, connector to distribution board (additional).	RD.5717	1	
Cover, cable eye, condensor, electric clock (additional).	RD.3106	1	
Eye, cable (Dowler).	RD.3690	20	
Eye, cable, electric clock (additional).	RD.3955	2	
Insulator, nipple, electric clock (additional).	RD.7547	1	
Nipple, electric clock (additional).	RD.7548	1	
Sleeve, rubber cable eye.	RD.7589	28	
LOOM, instrument board to dash assembly (R.C), as above except:	RD.7632	1	X
Cable, ammeter to regulator 'A1' (replaces RD.6020).	RD.7594	1	
Clip, cable, electric clock, cubby box door (additional).	RD.6082	1	
Eye, cable (Dowler).	RD.3533	2	
Sleeve, rubber cable eye.	RD.7589	29	
LOOM, instrument board to dash assembly (L.C) consisting of:	RD.5011	1	M/GG/HH
Cable switchbox '11' to distribution board '11'.	RD.3849	1	
Cable, front cigar lighter to distribution board '8'.	RD.3851	1	
Cable, demister switch to distribution board '11'.	RD.3852	1	
Cable, demister switch to 12-way junction box.	RD.5012	1	
Cable, switchbox '4' to 12-way junction box.	RD.3853	1	
Cable, switchbox '5' to distribution board '5'.	RD.3854	1	
Cable, switchbox '6' to distribution board '6'.	RD.3855	1	
Cable, earth, instrument board to dash.	RD.3856	1	
Cable, switchbox '10' to 12-way junction box.	RD.3858	1	
Cable, trafficator switch to distribution board '6'.	RD.3865	1	
Cable, trafficator switch L.H. to 12-way junction box.	RD.3870	1	
Cable, trafficator switch R.H. to 12-way junction box.	RD.3871	1	
Cable, wiper switch to 12-way junction box.	RD.3872	1	
Cable, heater switch to 12-way junction box.	RD.3874	1	
Cable, instrument light switch to distribution board '5'.	RD.3877	1	

GROUP Q20. (Continued Overleaf)

GROUP Q20. WIRING LOW TENSION AND FITTINGS. (Contd.)

	REF. NO.	QUANTITY GROUP	QUANTITY ASS'LY	NOTES
LOOM, instrument board to dash assembly (L.C) (Contd.)				
Cable, fuel oil switch to 12-way junction box (petrol tank unit).	RD. 3879		1	
Cable, fuel oil switch to 12-way junction box (oil sump unit).	RD. 3880		1	
Cable, fuel warning light to 12-way junction box.	RD. 3882		1	
Cable, ignition warning light to regulator 'D'.	RD. 3884		1	
Cable, coachbuilder's junction box to distribution board '8'.	RD. 3790		1	
Cable, speedometer warning light to coachbuilder's junction box.	RD. 4849		1	
Cable, switchbox positive to main fuse.	RD. 6017		1	
Cable, switchbox '2' to regulator 'A1'.	RD. 6018		1	
Cable, switchbox '8' to distribution board '8'.	RD. 6019		1	
Cable, ammeter to regulator 'A'.	RD. 6020		1	
Cable, fog lamp to 12-way junction box.	RD. 5014		1	
Cable, fog lamp switch to distribution board '5'.	RD. 5015		1	
Eye, cable 3 BA, (Lucas).	RD. 3344		8	
Eye, cable, cigar lighter (Smiths).	RD. 3956		1	
Eye, cable, 2 BA, (Dowler).	RD. 3533		1	
Eye, cable, 3 BA, (Dowler).	RD. 3690		17	
Sleeve.	RD. 7589		26	
Sleeving, 30 mm. instrument board to dashboard.	RD. 3080		1	
LOOM, instrument board to dash (L.C) as above except:	RD. 7564	1		JJ
Cable, electric clock (additional).	RD. 5716		1	
Cable, condensor to distribution board (additional).	RD. 5717		1	
Clip, cable electric clock, cubby box door (additional).	RD. 6082		1	
Cover, cable eye, condensor clock (additional).	RD. 3106		1	
Eye, cable (Dowler).	RD. 3690		20	
Eye, cable, electric clock (additional).	RD. 3955		2	
Insulator, nipple, electric clock (additional).	RD. 7547		1	
Nipple, electric clock (additional).	RD. 7548		1	
Sleeve, rubber, cable eye.	RD. 7589		27	
LOOM, instrument board to dash (L.C) as above except:	RD. 7633	1		X
Cable, ammeter to regulator 'A1' (replaces RD. 6020).	RD. 7594		1	
Eye, cable, 2 BA, (Dowler).	RD. 3533		2	
LOOM, assembly, rear (R.C).	RD. 3829	1		M
Cable, '5' to tail junction box.	RD. 3873		1	
Cable, distribution board '6' to body junction box companion.	RD. 3819		1	
Cable, distribution board '6' to reverse lamp switch.	RD. 3803		1	
Cable, distribution board '8' to body junction box cigar.	RD. 3792		1	
Cable, distribution board '11' to petrol pumps 'A' and 'B'.	RD. 3802		1	

GROUP Q20. (Continued Overleaf)

GROUP Q20. WIRING LOW TENSION AND FITTINGS. (Contd.)

	REF. NO.	PART NO.	QUANTITY GROUP	QUANTITY ASS'LY	NOTES
LOOM, assembly, rear (R.C) (Contd.).					
Cable, distribution board (-) to body junction box, roof light.		RD.3815		1	
Cable, 12-way junction box to body junction box, heater.		RD.3809		1	
Cable, 12-way junction box to body junction box (traff. L.H.).		RD.3805		1	
Cable, 12-way junction box to body junction box (traff. R.H.).		RD.3806		1	
Cable, 12-way junction box to fuel tank.		RD.3881		1	
Cable, 12-way junction box to fuel tank.		RD.3883		1	
Cable, reverse lamp switch to stop tail lamp switch.		RD.3804		1	
Cable, reverse lamp switch to tail junction box.		RD.3866		1	
Cable, stop light switch to tail junction box.		RD.3867		1	
Cable, body junction box to rear junction box, foot lamp.		RD.4264		1	
Eye, cable, 2 BA, (Lucas).		RD.3346		1	
Eye, cable, 2 BA, (Dowler).		RD.3533		1	
Eye, cable, 3 BA, (Dowler).		RD.3690		13	
Sleeve, rubber, cable eye.		RD.7589		15	
Sleeving, 18 mm.		RD.3087		1	
Sleeving, 11 mm. 2nd cross member to rear junction box.		RD.3091		1	
Sleeving, 11 mm. petrol tank unit.		RD.3092		1	
Sleeving, 11 mm. stop and reverse lamp switch body.		RD.3094		2	
Sleeving, 14 mm. main tank to body junction box.		RD.3095		1	
LOOM, assy. rear, (R.C) as above except:		RD.5464	1		KK
Sleeving, 14 mm. main trunk to body junction box. (Replaces RD.3095).		RD.5053		1	
LOOM, assy. rear, (R.C) as above except:		RD.7506	1		LL
Cable, 12-way junction box to petrol tank unit. (Replaces RD.3881).		RD.7501		1	
Cable, 12-way junction box to petrol tank unit. (Replaces RD.3883).		RD.6250		1	
Sleeving, 14 mm. main tank to 2nd cross member. (Replaces RD.3090).		RD.7502		1	
Sleeving, 11 mm. rear junction box to 2nd cross member. (Replaces RD.3091).		RD.7503		1	
Sleeving, 2nd cross member petrol tank unit. (Replaces RD.3092).		RD.7504		1	
LOOM, assy. rear (L.C) consisting of:		RD.5061	1		M/KK
Cable, distribution board '8' to body junction box. (Cigar).		RD.3792		1	

GROUP Q20. (Continued Overleaf)

GROUP Q20. WIRING LOW TENSION AND FITTINGS. (Contd.)

	REF. NO.	QUANTITY GROUP	QUANTITY ASS'LY	NOTES
LOOM, assembly, rear (L.C.) (Contd.)				
Cable, distribution board '11' to petrol pumps A & B.	RD.3802		1	
Cable, 12-way junction box to body junction box (Trafficator L.H).	RD.3805		1	
Cable, 12-way junction box to body junction box (Trafficator R.H).	RD.3806		1	
Cable, 12-way junction box to body junction box (Heater).	RD.3809		1	
Cable, distribution board (-) to body junction box (Roof Light).	RD.3815		1	
Cable, body junction box reverse lamp to tail junction box.	RD.5055		1	
Cable, body junction box, stop lamp to tail junction box.	RD.5056		1	
Cable, distribution board '5' to tail junction box.	RD.3873		1	
Cable, 12-way junction box to petrol tank unit.	RD.3881		1	
Cable, 12-way junction box to petrol tank unit.	RD.3883		1	
Cable, distribution board '6' to 6-way body junction box (Stop Lamp Switch).	RD.5028		1	
Eye, cable, 3 BA, (Dowler).	RD.3690		7	
Eye, cable, 2 BA, (Lucas).	RD.3346		1	
Eye, cable, 2 BA, (Dowler).	RD.3533		1	
Sleeve, rubber cable eye.	RD.7589		9	
Sleeving, 18 mm. main trunk.dash to rear.	RD.5052		1	
Sleeving, 14 mm. main trunk to 2nd cross-member.	RD.3090		1	
Sleeving, 11 mm. 2nd cross-member to tail junction box.	RD.3091		1	
Sleeving, 14 mm. trunk to R.H. body junction box.	RD.5053		1	
Sleeving, 11 mm. trunk to L.H. body junction box.	RD.5054		1	
Sleeving, 11 mm. petrol tank unit.	RD.3092		1	
LOOM, assembly rear (L.C.) as above except:	RD.7505	1		LL
Cable, 12-way junction box to petrol tank unit (Replaces RD.3881).	RD.7501		1	
Cable, 12-way junction box to petrol tank unit (Replaces RD.3883).	RD.6250		1	
Sleeving, 14 mm. main trunk to 2nd cross-member (Replaces RD.3090).	RD.7502		1	
Sleeving, 11 mm. 2nd cross-member to rear junction box (Replaces RD.3091).	RD.7503		1	
Sleeving, petrol tank unit (Replaces RD.3092).	RD.7504		1	

GROUP Q20. (Continued Overleaf)

GROUP Q20. WIRING LOW TENSION AND FITTINGS. (Contd.)

LOOM, valance plate, L.H. assembly (R.C), consisting of:	RD.3825	1		MM
Cable, 12-way junction box to L.H. front junction box (Horn).	RD.3860		1	
Cable, distribution board to L.H. front junction box (Pass).	RD.3863		1	
Cable, footswitch to L.H. front junction box (Head).	RD.3869		1	
Cable, distribution board '5' to L.H. front junction box (Side).	RD.3876		1	
Eye, cable 3 BA, (Dowler).	RD.3690		3	
Sleeve, rubber cable eye.	RD.7589		3	
Sleeving, 14 mm. dash to L.H. valance plate.	RD.3680		1	
LOOM, valance plate, L.H. assembly (R.C) as above except:	RD.5064	1		NN
Cable, 12-way junction box to L.H. front junction box (Horn). (Replaces RD.3860).	RD.6047		1	
Cable, distribution board L.H. front junction box (Pass). (Replaces RD.3863).	RD.6046		1	
Cable, footswitch to L.H. front junction box (Head). (Replaces RD.3869).	RD.6044		1	
Cable, distribution board '5' to L.H. front junction box side. (Replaces RD.3876).	RD.6043		1	
Sleeving, 14 mm. dash to L.H. valance plate (Replaces RD.3680).	RD.6050		1	
LOOM, valance plate, L.H. assembly. (R.C). as above except:	RD.5144	1		VT
Cable, footswitch to L.H. front junction box (Dip). (Additional).	RD.4557		1	
The following is omitted:				
Cable, distribution board to L.H. front junction box (Pass) RD.6046				
LOOM, valance plate, L.H. assembly (R.C) consisting of:	RD.5462	1		N
Cable, 12-way junction box to L.H. front junction box (Horn).	RD.5035		1	
Cable, footswitch to L.H. front junction box (Dip).	RD.5244		1	
Cable, footswitch to L.H. front junction box (Horn).	RD.5243		1	
Cable, distributor board '5' to L.H. front junction box (Side).	RD.5034		1	
Eye, cable, 3 BA. (Dowler).	RD.3690		3	
Sleeve, rubber cable eyes.	RD.7589		3	
Sleeving, 14 mm. L.H. valance plate.	RD.5458		1	

GROUP Q20. (Continued Overleaf)

GROUP Q20. WIRING LOW TENSION AND FITTINGS. (Contd.)

	REF. NO.	PART NO.	QUANTITY GROUP	QUANTITY ASS'LY	NOTES
LOOM, valance plate, L.H. assembly (L.C) consisting of:		RD.5030		1	
Cable, footswitch to L.H. front junction box (Head).		RD.5032		1	
Cable, footswitch, to L.H. front junction box (Head).		RD.5033		1	
Cable, distributor board '5' to L.H. front junction box (Side).		RD.5034		1	
Cable, 12-way junction box to L.H. front junction box (Horn).		RD.5035		1	
Cable, distributor board '8' to L.H. front junction box (Horn Relay).		RD.5036		1	
Cable, L.H. front junction box, horn relay to horn button.		RD.5166		1	
Eye, cable (Dowler).		RD.3690		4	
Sleeve, rubber.		RD.7589		4	
Sleeving, 14 mm. L.H. valance plate.		RD.5031		1	
Sleeving, 5 mm. L.H. valance plate to steering column.		RD.5163		1	
LOOM, valance plate, R.H. assembly (L.C).		RD.5037		1	M/GG/HH
Cable, footswitch to R.H. front junction box (Head) (Pink).		RD.5039		1	
Cable, footswitch to R.H. front junction box (Head) (White).		RD.5040		1	
Cable, coachbuilders' junction box to R.H. front junction box (Head).		RD.4859		1	
Cable, distribution board '5' to R.H. front junction box (Side).		RD.6042		1	
Cable, 12-way junction box to R.H. front junction box (Horn).		RD.6039		1	
Cable, main fuse to starter relay.		RD.5041		1	
Cable, 12-way junction box to R.H. front junction box (Fog).		RD.5042		1	
Cable, regulator 'F' to dynamo 'F'.		RD.6079		1	
Cable, regulator 'D' to dynamo 'D'.		RD.6078		1	
Cable, 12-way junction box to oil sump unit.		RD.6087		1	
Cable, 12-way junction box to starter relay 'H'.		RD.5043		1	
Cover, terminal, dynamo 'D'.		RD.3105		1	
Cover, terminal, dynamo 'F'.		RD.3106		1	
Eye, cable, 3 BA.		RD.3344		1	
Eye, cable, starter solonoid switch.		RD.3103		1	
Eye, cable, 2 BA.		RD.6081		1	
Eye, cable, .312" dia.		RD.3345		1	
Eye, cable, 3 BA.		RD.3690		4	
Sleeve, rubber.		RD.7589		7	
Sleeving, 18 mm. R.H. valance plate.		RD.5038		1	
Sleeving, 11 mm. dynamo.		RD.6086		1	
Sleeving, 5 mm. oil sump unit.		RD.6084		1	

GROUP Q20. (Continued Overleaf)

GROUP Q20. WIRING LOW TENSION AND FITTINGS. (Contd.)

	REF. NO.	PART NO.	QUANTITY GROUP	QUANTITY ASS'LY	NOTES
LOOM, valance plate R.H. (L.C) assembly, as above except:		RD.6430	1		
Cable, distributor board (-) to starter relay. (Additional).		RD.5521		1	
Cable, 12-way junction box to starter relay 'H'. (Replaces RD.5043).		RD.5523		1	
Eye. cable, 2 BA.		RD.6081		2	
The following parts have been deleted:					
Cable, main fuse to starter relay RD.5041.					
Eye cable to starter solonoid switch RD.3103.					
LOOM, R.H. valance plate assembly, consisting of:		RD.3827	1		MM
Cable, distribution board '8' to horn relay (Supply).		RD.3791		1	
Cable, horn relay, to horn, push button.		RD.3811		1	
Cable, 12-way junction box to oil sump unit.		RD.3818		1	
Cable, horn relay, to front junction box (Horn) R.H.		RD.3850		1	
Cable, 12-way junction box to R.H. front junction box (Horn).		RD.3859		1	
Cable, distribution board, to R.H. front junction box (Pass).		RD.3864		1	
Cable, footswitch to R.H. front junction box (Head).		RD.3868		1	
Cable, distribution board '5' to R.H. front junction box (Side).		RD.3875		1	
Cable, dynamo 'D' to regulator 'D'.		RD.4113		1	
Cable, dynamo 'F' to regulator 'F'.		RD.4115		1	
Cover, terminal, dynamo 'D'.		RD.3105		1	
Eye, cable, 3 BA, (Dowler).		RD.3690		5	
Eye, cable, 4 BA, (Lucas).		RD.3534		1	
Eye, cable, .312" dia. (Lucas).		RD.3345		1	
Eye, cable, 2 BA. (Dowler).		RD.3533		1	
Sleeve, rubber cable eye.		RD.7589		6	
Sleeving, 18 mm. R.H. valance plate.		RD.4000		1	
Sleeving, 14 mm. horn relay to steering column.		RD.4002		1	
Sleeving, 11 mm. horn relay to dynamo.		RD.4108		1	
LOOM, R.H. valance plate assembly, (R.C) as above except:		RD.6053	1		NN
Cable, horn relay to front junction box horn R.H. (Replaces RD.3850).		RD.6045		1	
Cable, 12-way junction box to R.H. front junction box horn (Replaces RD.3859).		RD.6039		1	
Cable, distribution board to R.H. front junction box pass (Replaces RD.3864).		RD.6040		1	
Cable, footswitch to R.H. front junction box head. (Replaces RD.3868).		RD.6041		1	
Cable, distribution board '5' to R.H. front junction box side. (Replaces RD.3875).		RD.6042		1	
Sleeving, 18 mm. R.H. valance plate (Replaces RD.4000).		RD.6049		1	

GROUP Q20. (Continued Overleaf)

GROUP Q20. WIRING LOW TENSION AND FITTINGS. (Contd.)

LOOM, R.H. valance plate, assembly (R.C). as above except:	RD.5142	1		V
Cable, 12-way junction box to R.H. front junction box fog. (Additional).	RD.4554		1	
Cable, footswitch to R.H. front junction box dip. (Additional.)	RD.4556		1	
The following piece Nos. have been deleted:				
Cable distribution board to R.H. front junction box pass RD.6040.				
LOOM, R.H. valance plate, assembly (R.C), as above, except:	RD.6091	1		T
Cable, dynamo 'D' to regulator 'D'. (Replaces RD.4113).	RD.6078		1	
Cable, dynamo 'F' to regulator 'F'. (Replaces RD.4115).	RD.6079		1	
Cable, 12-way junction box to oil sump unit. (Replaces RD.3818).	RD.6087		1	
Cover, terminal, dynamo 'F'. (Additional).	RD.3106		1	
Eye, cable, dynamo 'F'.	RD.6081		1	
Sleeving, 18 mm. R.H. valance plate. (Replaces RD.6049).	RD.6083		1	
Sleeving, 5 mm. oil sump unit. (Additional).	RD.6084		1	
Sleeving, 5 mm. relay to steering column. (Additional).	RD.6085		1	
Sleeving, 11 mm. dynamo oil sump unit. (Additional).	RD.6086		1	
Sleeve, rubber.	RD.7589		5	
The following pieces have been deleted:				
Cable, eye, (Lucas) RD.3345.				
Cable, eye, (Dowler) RD.3535.				
Sleeving, 14 mm. horn relay to steering column. RD.4002.				
Sleeving, 11 mm. horn relay to dynamo. RD.4108.				
LOOM, R.H. valance plate, assembly (R.C) as above except:	RD.5170	1		T
Cable, coachbuilders' junction box to R.H. front junction box head. (Additional).	RD.4859		1	
Eye, cable, (Lucas). (Additional).	RD.3345		1	
LOOM, R.H. valance plate, assembly (R.C), as above, except:	RD.5463	1		N
Cable, 12-way junction to R.H. front junction box fog. (Replaces RD.4554).	RD.5042		1	
Cable, footswitch to R.H. front junction box head. (Replaces RD.6041).	RD.5234		1	
Cable, footswitch to R.H. front junction box dip. (Replaces RD.4556).	RD.5235		1	
Eye, cable. (Dowler).	RD.3690		7	
Sleeve, rubber.	RD.7589		7	

GROUP Q20. (Continued Overleaf)

GROUP Q20. WIRING LOW TENSION AND FITTINGS. (Contd.)

LOOM, assembly, dashboard (R.C), consisting of:	RD.5461	1		GG/HH
Cable, distribution board, '11' to ignition coil.	RD.5025		1	
Cable, 12-way junction box to wiper motor.	RD.5026		1	
Cable, 12-way junction box to demister blower.	RD.5159		1	
Cable, earth demister blower.	RD.5162		1	
Cable, 12-way junction box to footswitch.	RD.5233		1	
Cable, distribution board (-) to starter relay.	RD.5456		1	
Cable, 12-way junction box to starter relay 'H'.	RD.5457		1	
Eye, cable 3 BA. (Lucas).	RD.3344		1	
Eye, cable starter solonoid switch.	RD.3103		1	
Eye, cable, 2 BA. (Dowler).	RD.3533		1	
Eye, cable, 3 BA. (Dowler).	RD.3690		2	
Eye, cable, .312" dia. (Lucas).	RD.3345		1	
Sleeve, rubber.	RD.7589		6	
Sleeving, 18 mm. dashboard.	RD.5021		1	
Sleeving, 7 mm. demister blower.	RD.5022		1	
Sleeving, 5 mm. ignition coil.	RD.5023		1	
Sleeving, 5 mm. wiper motor.	RD.5024		1	
Sleeving, 11 mm. footswitch.	RD.5232		1	
Sleeving, 5 mm. horizontal sleeve to dash.	RD.5245		1	
LOOM, assembly, dashboard, (R.C) as above except:	RD.6428	1		OO
Cable, distributor board (-) to starter relay. (Replaces RD.5456).	RD.5520		1	
Cable, 12-way junction box to starter relay 'H'. (Replaces RD.5457).	RD.5522		1	
Eye, cable, starter solonoid switch. (Additional).	RD.5801		1	
Eye, cable, starter solonoid switch 'H'.	RD.6081		1	
The following piece has been omitted:- Eye cable starter solonoid switch RD.3103.				
LOOM, assembly, dashboard, (R.C), as above except:	RD.6764	1		PP
Cable, 12-way junction box to demister blower. (Replaces RD.5159).	RD.5954		1	
Cable, earth, demister blower. (Replaces RD.5162).	RD.5953		1	
Sleeving, 7 mm. dash, trunk to demister. (Replaces RD.5022).	RD.5952		1	
Sleeving, 5 mm. demister blower. (Replaces RD.5245).	RD.5951		1	
LOOM, assembly, dashboard (L.C), consisting of:	RD.5020	1		QQ
Cable, distribution board '11' to ignition coil.	RD.5025		1	
Cable, 12-way junction box to wiper motor.	RD.5026		1	
Cable, 12-way junction box to footswitch supply.	RD.5027		1	
Cable, 12-way junction box to demister blower.	RD.5159		1	
Cable, earth demister blower.	RD.5162		1	
Eye, cable, 3 BA. (Dowler).	RD.3690		1	
Eye, cable, 2 BA. (Dowler).	RD.3533		1	
Eye, cable, .312" dia. (Lucas).	RD.3345		1	
Sleeve, rubber.	RD.7589		4	

GROUP Q20. (Continued Overleaf).

GROUP Q20. WIRING LOW TENSION AND FITTINGS. (Contd.)

	REF. NO.	PART NO.	QUANTITY GROUP ASS'LY	NOTES
LOOM, assembly, dashboard (L.C). (Contd.)				
Sleeving, 5 mm. demister blower.		RD.5245	1	
Sleeving, 18 mm. dashboard.		RD.5021	1	
Sleeving, 7 mm. demister blower.		RD.5022	1	
Sleeving, 5 mm. ignition coil.		RD.5023	1	
Sleeving, 5 mm. wiper motor.		RD.5024	1	
LOOM, assembly, dashboard (L.C) as above, except:		RD.6451	1	RR
Cable, distribution board to charging plug connector.		RD.5748	1	
Cable, regulator 'E' to connector.		RD.5752	1	
Connector, male, cables charging plug.		RD.5745	2	
Eye, cable 3 BA. (Lucas).		RD.3344	1	
Sleeve, rubber cable eyes.		RD.7589	5	
Sleeving, 11 mm. charging plug connector.		RD.5759	1	
LOOM, assembly, dashboard (L.C) as above, except:		RD.6765	1	SS
Cable, earth demister blower. (Replaces RD.5162).		RD.5953	1	
Cable, 12-way junction box to demister blower. (Replaces RD.5159).		RD.5954	1	
Sleeving, 5 mm. demister blower. (Replaces RD.5245).		RD.5951	1	
Sleeving, 7 mm. dash trunk to demister. (Additional).		RD.5952	1	
The following piece has been omitted:- Sleeving, 7 mm. demister blower RD.5022.				
LOOM, assembly, charging plug to dashboard (L.C) consisting of:		RD.5016	1	QQ
Cable, earth charging plug to regulator 'E'.		RD.5018	1	
Cable, charging plug to distribution board.		RD.5019	1	
Eye, cable 3 BA. (Lucas).		RD.3344	3	
Sleeve, rubber cable eye.		RD.7589	3	
Sleeving, charging plug to dash.		RD.5017	1	
LOOM, assembly, charging plug consisting of:		RD.5755/6A	1	U(R.C) RR/SS(L.C)
Cable, regulator 'E' connector to charging plug.		RD.5755	1	
Cable, distribution board connector to charging plug.		RD.5756	1	
Connector female cables, charging plug.		RD.5746	2	
Eye, cable, 3 BA. (Lucas).		RD.3344	2	
Sleeve, rubber cable eye.		RD.7589	2	
Sleeve, rubber connectors.		RD.3305	2	
Sleeving, 11 mm. connector to charging plug.		RD.5757	1	

GROUP Q20 (Continued overleaf)

GROUP Q20. WIRING LOW TENSION AND FITTINGS. (Contd.)

LOOM, assembly, cruciform (L.C).	RD.5044	1		
Cable, reverse lamp switch to stop lamp switch.	RD.5048		1	
Cable, reverse lamp switch to body 4-way junction box. (Blue).	RD.5049		1	
Cable, stop lamp switch to body 4-way junction box. (White).	RD.5050		1	
Cable, stop lamp switch to body 4-way junction box.	RD.5051		1	
Cable, body 4-way to body 6-way junction boxes.	RD.5167		1	
Cable, body 6-way to car heater 4-way junction boxes.	RD.5182		1	
Cable earth, 4-way junction box (car heater).	RD.5183		1	
Sleeve, rubber.	RD.7589		6	
Sleeving, 11 mm. reverse lamp switch.	RD.5046		1	
Sleeving, 11 mm. stop lamp switch.	RD.5047			
Sleeving, 7 mm. 4-way junction box, car heater.	RD.5181		1	
NUT, 2 BA, clip heater sleeving.	K. 4006/Z	1		J
NUT, 3 BA, earth terminal valance plates.	K. 4304/Z	2		
NUT, 3 BA, earth terminal valance plates.	K. 4005/Z	2		
NUT, 2 BA, clip wiring harness (R.C).	K. 4006/Z	25		O
NUT, 2 BA, clip wiring harness (R.C).	K. 4006/Z	17		P
NUT, 2 BA, clip wiring harness (R.C).	K. 4006/Z	18		Q
NUT, 2 BA, clip wiring harness (R.C).	K. 4006/Z	19		N
NUT, 2 BA, clip wiring harness (L.C).	K. 4006/Z	27		
SCREW, cheese-head 3 BA, earth terminal valance plate.	K. 1813/Z	2		
SCREW, 2 BA, clips, R.H. valance plate, horn sleeving (R.C).	K. 1910/Z	2		
SCREW, 2 BA, clips, R.H. valance plate, 18 mm. sleeving (R.C).	K. 1904/Z	3		
SCREW, 2 BA, clips, L.H. valance plate, 14 mm. sleeving (R.C).	K. 1904/Z	3		
SCREW, cheese-head, 2 BA, clips L.H. valance plate (L.C).	K. 1904/Z	5		
SCREW, cheese-head, 2 BA, clips R.H. valance plate (L.C).	K. 1904/Z	3		
SLEEVE, rubber, cable oil sump unit.	RD.7589	2		S
SLEEVE, rubber ignition cable.	RD.3305	3		
SLEEVE, rubber, cable oil sump unit.	RD.7589	2		U/V
WASHER, FS. 3 BA, earth terminal valance plate.	K. 9005/Z	4		
WASHER, FS. 2 BA, clips sleeving R.H. valance plate (R.C).	K. 9006/Z	5		
WASHER, FS. 2 BA, clips sleeving R.H. valance plate (L.C).	K. 9006/Z	3		
WASHER, FS. 2 BA, clip heater sleeving.	K. 9006/Z	2		J
WASHER, FS. 2 BA, clip sleeving L.H. valance plate (R.C).	K. 9006/Z	3		
WASHER, FS. 2 BA, clip sleeving L.H. valance plate (L.C).	K. 9006/Z	5		
WASHER, FS. 2 BA, clip sleeving battery to switch.	K. 9006/Z	5		
WASHER, FS. 2 BA, clip rear loom.	K. 9006/Z	12		
WASHER, FS. 2 BA, clip cruciform loom (L.C).	K. 9006/Z	8		
WASHER, plain 3 BA, earth terminal, valance plate.	K. 4446/Z	6		

GROUP Q21. WIRING FOR STANDARD BODY.

Comprising:

	REF. NO.	QUANTITY GROUP	QUANTITY ASSLY	NOTES
CABLE, boot lamp switch to rear junction box, (White).	RD.4256	1		VV
CABLE, boot lamp switch to rear junction box, (Green).	RD.4712	1		WW
CABLE, centre lamp to R.H. front junction box.	RD.4750	1		
CABLE, cigar lighter rear to earth.	RD.3982	1		
CABLE, companion to earth.	RD.3985	2		
CABLE, companion switch to light.	RD.3984	2		
CABLE, door switch, front to rear (Purple).	RD.4755	2		YY
CABLE, door switch, front to rear (Light Blue).	RD.4756	2		YY
CABLE, earth, R.H. stop tail to rear junction box.	RD.4830	1		
CABLE, earth, L.H. stop tail to rear junction box.	RD.4833	1		
CABLE, earth, rear junction box.	RD.4652	1		
CABLE, earth, rear junction box to number plate box (R.C).	RD.4799	1		
CABLE, earth, number plate to L.H. reverse lamp (L.C).	RD.4720	1		
CABLE, earth, reverse lamp L.H. to R.H. (L.C).	RD.4721	1		
CABLE, R.H. reverse lamp to rear junction box (L.C).	RD.4722	1		
CABLE, headlamps to front junction box.	RD.6052	2		R
CABLE, headlamps to front junction box.	RD.4996	2		V/W/X
CABLE, heater junction box to earth (R.C).	RD.5183	1		J
CABLE, junction box rear to R.H. reverse lamp (L.C).	RD.4719	1		
CABLE, junction box, rear to R.H. reverse lamp (R.C).	RD.4738	1		
CABLE, junction box to number box R.H. (illumination) (R.C).	RD.4800	1		
CABLE, junction box to number box L.H. (illumination) (R.C).	RD.4736	1		
CABLE, junction box to L.H. reverse lamp (R.C).	RD.4737	1		
CABLE, number plate lamp to rear junction box (L.C).	RD.4341	1		
CABLE, L.H. reverse lamp to rear junction box (L.C).	RD.4718	1		
CABLE, roof light to earth.	RD.4740	1		
CABLE, tail light R.H. to rear junction box.	RD.4828	1		
CABLE, tail light L.H. to rear junction box.	RD.4831	1		
CABLE, trafficator to earth.	RD.3988	2		
CABLE, sidelamp to front junction box.	RD.6051	2		
CABLE, stop light R.H. to rear junction box.	RD.4829	1		
CABLE, stop light L.H. to rear junction box.	RD.4832	1		
CLIP, spring (11 mm. sleeve).	RD.3434	-		
CLIP, spring (.750" sleeve).	RD.7550	-		
CLIP, spring (5 mm. sleeve).	RD.4257	-		
CLIP, screwed, .250" dia.	RD.6082	-		
CLIP, screwed, .500" dia.	RD.3041	-		
CLIP, screwed, .750" dia.	RD.7551	-		
CLIP, screwed, .375" dia.	RD.6169	-		
GROMMET, rubber, .500" internal dia.	RD.3436	-		
GROMMET, rubber, .625" internal dia.	RD.5356	-		
LOOM, assembly, body junction box to R.H. companion (R.C). consisting of:	RD.3992	1		VV
Cable, body junction box to R.H. roof light switch.	RD.3977		1	
Cable, body junction box to rear cigar lighter.	RD.3981		1	

GROUP Q21. (Continued Overleaf)

GROUP Q21. WIRING FOR STANDARD BODY. (Contd.)

	REF. NO.	PART NO.	QUANTITY GROUP	QUANTITY ASSY.	NOTES
LOOM, assembly, body junction box to R.H. companion (R.C). (Contd.)					
Cable, body junction box to R.H. companion light switch.		RD.3983		1	
Cable, body junction box to R.H. trafficator.		RD.3987		1	
LOOM, assembly, body junction box to L.H. trafficator (R.C). consisting of:		RD.3993	1		VV
Cable, body junction box to L.H. trafficator.		RD.3989		1	
Cable, body junction box to car heater.		RD.3990		1	
Cable, car heater to earth.		RD.3991		1	
LOOM, assembly, body junction box to R.H. companion (R.C) as RD.3992 but Cable RD.3977 deleted.		RD.4686	1		WW/XX
LOOM, assembly, body junction box to L.H. roof light switch (R.C). as RD.3993 assembly, except:		RD.4687	1		WW/XX
Cable, body junction box, to L.H. roof light switch (Additional).		RD.4653		1	
LOOM, assembly, junction box to L.H. roof light switch (R.C). Consisting of:		RD.5830	1		J/XX
Cable, body, junction box to L.H. trafficator.		RD.3989		1	
Cable, body, junction box to car heater.		RD.5406		1	
Cable, body, junction box to L.H. roof light switch.		RD.4653		1	
LOOM, assembly, body junction box to R.H. companion (R.C). Consisting of:		RD.5226	1		YY
Cable, body, junction box to R.H. rear door switch. (Additional).		RD.4753		1	
Cable, R.H. rear door switch to roof lamp.		RD.4760		1	
LOOM, assembly, body junction box to L.H. companion (R.C). Consisting of:		RD.5408	1		YY
Cable, body junction box to L.H. trafficator.		RD.3989		1	
Cable, body junction box to car heater.		RD.5406		1	
Cable, body junction box to L.H. front door switch.		RD.4754		1	
Cable, L.H. front door switch to L.H. roof light switch. (Purple).		RD.4757		1	
Cable, L.H. front door switch to L.H. roof light switch (Light Blue).		RD.4758		1	
Cable, L.H. rear door switch to roof light.		RD.4759		1	

GROUP Q21. (Continued Overleaf)

GROUP Q21. WIRING FOR STANDARD BODY. (Contd.)

LOOM, assembly, body junction box to R.H. companion (L.C) consisting of:	RD.5211	1		
Cable, body junction box to rear door switch.	RD.4753		1	
Cable, front door switch to R.H. roof light switch. (Purple).	RD.4757		1	
Cable, front door switch to R.H. roof light switch. (Light Blue).	RD.4758		1	
Cable, rear door switch to roof light.	RD.4760		1	
Cable, body junction box to R.H. trafficator.	RD.3787		1	
Cable, body junction box to cigar lighter.	RD.3981		1	
Cable, body junction box to R.H. companion switch.	RD.3983		1	
LOOM, assembly, body junction box to L.H. companion (L.C) consisting of:	RD.5112	1		
Cable, body junction box to L.H. trafficator.	RD.3989		1	
Cable, body junction box to rear door switch.	RD.4754		1	
Cable, rear door switch to roof light.	RD.4759		1	
LOOM, assembly, R.H. to L.H. companion with:	RD.5213	1		
Cable, R.H. to L.H. companion light switch.	RD.3986		1	
LOOM, assembly R.H. to L.H. roof light switch (R.C). Consisting of:	RD.3994	1		VV
Cable, R.H. to L.H. roof light switches.	RD.3978		2	
Cable, L.H. roof light switch to roof light.	RD.3979		1	
Cable, R.H. to L.H. companion light switches.	RD.3986		1	
LOOM, assembly, L.H. roof light switch to roof light (R.C), consisting of:	RD.4656	1		WW/XX
Cable, R.H. to L.H. companion light switches.	RD.3986		1	
Cable, L.H. roof light switch to roof light.	RD.4693		1	
NUT, locking, 2 BA.	K. 4307/Z			
SCREW, 2 BA.	K. 1904/Z			
SCREW, cheese-head, fixing junction box, rear.	K. 1807/Z	2		
SCREW, cheese-head, with terminal rear junction box.	K. 1810/Z	1		
SCREW, cheese-head, earth terminals, roof light and companions.	K. 1807/Z	3		
SLEEVING, cable, centre lamp to R.H. front junction box.	RD.4826	1		
SLEEVING, 11 mm. R.H. stop tail lamp to rear junction box.	RD.3523	1		
SLEEVING, 11 mm. L.H. stop tail lamp to rear junction box.	RD.3524	1		
SLEEVING, 11 mm. L.H. companion. (R.C).	RD.3541	1		XX
SLEEVING, heater junction box to earth.	RD.5181	1		
SLEEVING, rear junction box to rear number plate (R.C) (with RD.4588 number plate).	RD.3496	1		
SLEEVING, rear junction box to rear number plate (R.C) (with RD.5677 number plate.)	RD.6267	1		
SLEEVING, R.H. to L.H. number plate (R.C).	RD.4620	1		

GROUP Q1

GROUP Q2

GROUP Q3

GROUP Q4

BENTLEY MOTORS (1931) LIMITED

GROUP Q5

BENTLEY MOTORS (1931) LIMITED

GROUP Q6

GROUP Q7

GROUP Q8

28
13
11
2
36
41
X24
X85
16
9
20
17
32
12
X46
5
6
25
X55
14
39
33
X87
4
19
10
34
1
22
30
10
7
X54
31
35
23
40
24
14
7

37
21
29
18
8
3
26
38
X24
41
X54
27

GROUP Q8A

GROUP Q9

BENTLEY MOTORS (1931) LIMITED

GROUP-Q10

BENTLEY MOTORS (1931) LIMITED

GROUP Q11

GROUP Q11

GROUP Q 12

BENTLEY MOTORS (1931) LIMITED

GROUP Q13-13A-13B

GROUP Q14

GROUP Q 14A

BENTLEY MOTORS (1931) LIMITED

GROUP Q15

BENTLEY MOTORS (1931) LIMITED

GROUP Q16

GROUP Q17

GROUP Q18

GROUP Q18A

BENTLEY MOTORS (1931) LIMITED

GROUP Q19

BENTLEY MOTORS (1931) LIMITED